
L-IOB™ I/O Controller

LIOB-180, LIOB-181, LIOB-182, LIOB-183, LIOB-184
LIOB-480, LIOB-481, LIOB-482, LIOB-483, LIOB-484
LIOB-580, LIOB-581, LIOB-582, LIOB-583, LIOB-584
LIOB-585, LIOB-586, LIOB-587, LIOB-588, LIOB-589
LIOB-590, LIOB-591, LIOB-592, LIOB-593, LIOB-594
LIOB-595, LIOB-596

User Manual

Delta IBT (Europe) GmbH



Contact

Delta Intelligent Building Technologies (Europe) GmbH
Blumengasse 35
1170 Vienna
AUSTRIA/EUROPE
support@loytec.com
<http://www.loytec.com>

Version 8.6

Document № 88080317

DELTA IBT (EUROPE) MAKES AND YOU RECEIVE NO WARRANTIES OR CONDITIONS, EXPRESS, IMPLIED, STATUTORY OR IN ANY COMMUNICATION WITH YOU, AND DELTA IBT (EUROPE) SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THIS PRODUCT IS NOT DESIGNED OR INTENDED FOR USE IN EQUIPMENT INTENDED FOR SURGICAL IMPLANT INTO THE BODY OR OTHER APPLICATIONS INTENDED TO SUPPORT OR SUSTAIN LIFE, FOR USE IN FLIGHT CONTROL OR ENGINE CONTROL EQUIPMENT WITHIN AN AIRCRAFT, OR FOR ANY OTHER APPLICATION IN WHICH IN THE FAILURE OF SUCH PRODUCT COULD CREATE A SITUATION IN WHICH PERSONAL INJURY OR DEATH MAY OCCUR.

DELTA IBT (EUROPE) MAKES NO REPRESENTATION AND OFFERS NO WARRANTY OF ANY KIND REGARDING OF ANY THIRDPARTY COMPONENTS MENTIONED IN THIS MANUAL.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Delta IBT (Europe).

LC3020™, L-Chip™, L-Core™, L-DALI™, L-GATE™, L-INX™, L-IOB™, LIOB-Connect™, LIOB-FT™, L-IP™, LPA™, L-Proxy™, L-Switch™, L-Term™, L-VIS™, L-WEB™, L-ZIBI™ and ORION™ stack are trademarks of Delta Intelligent Building Technologies (Europe) GmbH.

LonTalk®, LONWORKS®, Neuron®, LONMARK®, LonMaker®, i.LON®, and LNS® are trademarks of Echelon Corporation registered in the United States and other countries.

Contents

1	Introduction	8
1.1	Overview	8
1.2	L-IOB Models.....	8
1.3	Scope.....	9
2	Disclaimer Cyber Security	11
3	Safety Instructions.....	12
4	What's New	18
4.1	New in L-IOB I/O Controller 8.6.0	18
4.2	New in L-IOB I/O Controller 8.4.0	19
4.3	New in L-IOB I/O Controller 8.2.0	21
4.4	New in L-IOB I/O Controller 8.0.0	22
4.5	New in L-IOB I/O Controller 7.6.0	24
4.6	New in L-IOB I/O Controller 7.4.0	25
4.7	New in L-IOB I/O Controller 7.2.0	28
4.8	New in LIOB-x8x 7.0.0.....	32
4.9	New in LIOB-x8x 6.4.0.....	34
4.10	New in LIOB-x8x 6.2.0.....	36
4.11	New in LIOB-x8x 6.1.0.....	37
4.12	New in LIOB-x8x 6.0.0.....	38
4.13	New in LIOB-x8x 5.3.0.....	40
4.14	New in LIOB-x8x 5.1.0.....	41
4.15	New in LIOB-x8x 5.0.0.....	43
5	Quick-Start Guide	47
5.1	Hardware Installation.....	47
5.2	Commissioning or BACnet Setup	47
5.3	Getting Started With the L-INX Configurator.....	49
5.4	Configuration of the I/Os.....	50
5.5	Getting Started With L-STUDIO	51
5.6	Getting Started With logiCAD	57
6	Hardware Installation	63
6.1	Enclosure.....	63
6.2	Product Label	63
6.3	Mounting.....	63
6.4	Power Supply and Wiring	64
6.4.1	CEA-709 Network Connection in Free Topology	64
6.4.2	CEA-709 Network Connection in Bus Topology	64

6.4.3	CEA-852 Network Connection	65
6.4.4	BACnet/IP Network Connection	66
6.4.5	Extension of LIOB-48x/58x Controllers With LIOB-45x/55x/56x Device 66	
6.5	LED Signals.....	66
6.5.1	Status LED of LIOB-18x	66
6.5.2	Status LED of LIOB-48x	67
6.5.3	Status LED of LIOB-58x/59x	67
6.6	Status Button and Factory Defaults	67
7	Concepts	69
7.1	Device Installation	69
7.2	LONMARK® Device Mode (LIOB-18x/48x)	69
7.3	Data Point Configuration.....	70
7.4	IEC61131 Variables.....	70
8	IEC 61131.....	72
8.1	Overview.....	72
8.2	Installing logiCAD	72
8.2.1	Softlock License	73
8.2.2	Hardlock License.....	74
8.3	IEC61131 Project Files.....	75
8.4	Working With logiCAD	76
8.4.1	Managing Variables	78
8.4.2	Build and Download the IEC61131 Program.....	79
8.4.3	Usage of NVs, Technology Converters (LIOB-18x/48x).....	80
8.4.4	IEC61131 Program Cycle Time	81
8.4.5	CPU Overload	82
8.4.6	I/O Driver Settings	83
8.4.7	PLC Conflicts	83
8.5	Workflows	84
8.5.1	Starting With Data Points.....	84
8.5.2	Starting With logiCAD.....	85
8.5.3	Pre-compiled IEC61131 Program	91
8.6	Additional Features	92
8.6.1	Force Update Functionality	92
8.6.2	Using UNVT Variables (LIOB-18x/48x).....	92
8.6.3	Create Your Own Data Type.....	93
8.6.4	Using Persistent Data Points and Markers	93
8.6.5	Using Retain Variables.....	94
8.6.6	System Registers, System Time	94
8.6.7	Code Protection	95

8.6.8 Using Structured Data Point Members	95
8.6.9 BACnet Server Objects (LIOB-58x).....	96
9 Firmware Update.....	98
9.1 Firmware Update Via the Configurator.....	98
9.2 Firmware Update Via the Web Interface (LIOB-48x/58x).....	99
9.3 Firmware Update Via the USB Port.....	99
10 Troubleshooting.....	100
10.1 Technical Support	100
10.2 Remote Packet Capture (LIOB-48x/58x)	100
11 Application Notes.....	101
11.1 External Power Supply (Not Using LPOW-2415A)	101
11.2 Physical Connection of Inputs.....	101
11.2.1 Connection of Switches	101
11.2.2 Connection of S0 Pulse Devices (Meters)	102
11.2.3 Connection of Voltage Sources to Universal Inputs	103
11.2.4 Connection of 4-20mA Transmitters to Universal Inputs	103
11.2.5 Connection of Resistive Sensors.....	104
11.2.6 Connection of STId Card Readers	104
11.3 Physical Connection of Outputs.....	105
11.3.1 6A Relays With One External Fuse	105
11.3.2 6A Relays on LIOB-xx2 Using Separate Fuses	105
11.3.3 16A and 6A Relays on LIOB-xx3.....	106
11.3.4 10A Relays on LIOB-586/587	106
11.3.5 6A Relays on LIOB-588/589	107
11.3.6 External Relays and Inductive Loads.....	107
11.3.7 Triacs	108
11.3.8 Analog Outputs.....	108
11.4 Redundant Ethernet (LIOB-48x/58x).....	108
11.4.1 Ethernet Cabling Options.....	108
11.4.2 Upstream Options	110
11.4.3 Preconditions	110
11.4.4 Switch Settings	111
11.4.5 Testing	111
11.4.6 Example Switch Configuration	112
12 Security Hardening Guide	113
12.1 Installation Instructions.....	113
12.2 Firmware.....	113
12.3 Ports	113
12.4 Services.....	114

12.5	Upgrade Key Strength.....	115
12.6	Logging and Auditing.....	116
12.7	Network Access	116
12.8	Password Protection	116
12.9	Encryption-At-Rest	116
12.10	Secure Disposal and Decommissioning	117
12.11	Information Policy	117
13	Specifications	118
13.1	I/O Specification	118
13.1.1	UI - Universal Input	118
13.1.2	DI - Digital Input, Counter Input (S0-Pulse).....	119
13.1.3	AO - Analog Output	119
13.1.4	DO - Digital Output.....	119
13.1.5	PRESS - Pressure Sensor	119
13.1.6	IO – Universal Analog/Digital Input/output.....	119
13.1.7	O – 4-20mA Current Output.....	120
13.2	Internal Translation Tables	121
13.3	Specification for LIOB-18x Models.....	122
13.4	Specification for LIOB-48x Models.....	123
13.5	Specification for LIOB-580/581/582/583/584 Models	124
13.6	Specification for LIOB-585/586/587/588/589.....	125
13.7	Specification for LIOB-590/591/592.....	126
13.8	Specification for LIOB-593/594/595/596.....	127
13.9	Resource Limits	128
14	References	130
15	Revision History	131

Abbreviations

AST	Alarming, Scheduling, Trending
BACnet	Building Automation and Control Network
CEA-709	Protocol standard for LONWORKS networks
CEA-852	Protocol standard for CEA-709 over IP networks
COV	Change-Of-Value
CP	Configuration Property
CS	Configuration Server that manages CEA-852 IP devices
DHCP	Dynamic Host Configuration Protocol, RFC 2131, RFC 2132
I/O	Input/Output
LIOB	LOYTEC I/O bus
MAC	Media Access Control
NAT	Network Address Translation, see Internet RFC 1631
NTC	Negative Temperature Coefficient (Temperature Sensor)
NV	Network Variable
OPC	Open Process Control
PTC	Positive Temperature Coefficient (Temperature Sensor)
SCPT	Standard Configuration Property Type
SNVT	Standard Network Variable Type
UCPT	User-Defined Configuration Property Type
UI	User Interface

1 Introduction

1.1 Overview

The L-IOB I/O controllers LIOB-18x, LIOB-48x, LIOB-58x, and LIOB-59x combine physical inputs and outputs (I/Os) with programmable logic (IEC61131) and provide application specific data points through a CEA-709 or BACnet connection. The data points are also subject to AST (alarming, scheduling, and trending) functions of the L-IOB I/O controller. The I/O controllers come in different models with different I/O configurations, including analog outputs, digital outputs, digital inputs, and universal inputs, which can be freely configured. Some models feature a 2-port Ethernet switch. All LIOB-58x/59x models are BTL-certified as B-BC devices.

Initial configuration of the I/O controllers is accomplished through the L-INX Configurator software. The logic application is developed using the provided IEC-61131 compliant design tool. Parameterization of I/Os, self-test, manual modes, override values, etc. can also be performed on the L-IOB LCD display.

1.2 L-IOB Models

This Section provides an overview of the different L-IOB models in Table 1. This table identifies the different features of those models. Models that possess a certain feature have a check mark (✓) in the respective column. If a feature is not available in the particular model, the column is left blank.

On models with BACnet either BACnet MS/TP or BACnet/IP can be enabled (see note 1 in Table 1). Some BACnet models have a restriction on Modbus RTU and BACnet MS/TP as they share the same port. On those models Modbus RTU can only be used, if BACnet MS/TP is disabled (see note 2 in Table 1).

Model Features	LIOB-18X	LIOB-48X	LIOB-48X V2	LIOB-580-584	LIOB-58X V2	LIOB-585	LIOB-586	LIOB-587	LIOB-588/589	LIOB-590	LIOB-591	LIOB-592	LIOB-593	LIOB-594	LIOB-595/596
CEA-709 (FT)	✓														
CEA-852 (IP)		✓	✓			✓	✓	✓	✓	✓		✓	✓	✓	✓
BACnet MS/TP						✓	✓	✓	✓		✓ ¹	✓	✓	✓	✓
BACnet IP				✓	✓	✓	✓	✓	✓	✓	✓ ¹	✓	✓	✓	✓
BBMD				✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
BACnet/SC					✓	✓	✓	✓	✓	✓	✓ ¹	✓ ¹	✓	✓	✓
Modbus RTU						✓ ²	✓ ²	✓ ²	✓ ²		✓ ²	✓ ²	✓ ²	✓ ²	✓ ²
Modbus IP						✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
M-Bus							✓ ³	✓ ³	✓ ³						
MP-Bus						✓	✓ ⁵	✓ ⁵	✓ ⁵		✓ ⁵	✓ ⁵	✓	✓	✓
EnOcean						✓ ³	✓ ³	✓ ³	✓ ³		✓ ³	✓ ³	✓ ³	✓ ³	✓ ³
SMI											✓ ³	✓ ³			
LRS232-802							✓	✓	✓		✓	✓			
OPC XML-DA		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
OPC UA			✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
OPC Client						✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
SNMP			✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
PLC (L-LOGICAD)	✓	✓	✓	✓	✓	✓	✓		✓						
PLC (L-STUDIO)			✓ ⁴		✓ ⁴	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
LIOB Connect							✓	✓	✓						
LIOB IP		✓	✓	✓	✓		✓	✓	✓		✓		✓		
LCD Display	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
USB						✓	✓	✓	✓		✓	✓	✓	✓	✓
Ethernet Switch/Hub		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
WLAN, LTE						✓ ³	✓ ³	✓ ³	✓ ³		✓ ³	✓ ³	✓ ³	✓ ³	✓ ³
SSH, HTTPS, Firewall			✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Script Support						✓ ⁴	✓ ⁴	✓ ⁴	✓ ⁴	✓ ⁴	✓ ⁴	✓ ⁴	✓ ⁴	✓ ⁴	✓ ⁴

¹ This model can be configured to have either MS/TP or IP or SC active for BACnet.

² Modbus RTU can only be used, if BACnet MS/TP is not active on this model.

³ To operate these protocols an expansion module is needed and must be ordered separately.

⁴ These models require a separate license that needs to be purchased to use this feature.

⁵ These models can be extended by 2 x LMPBUS-804.

Table 1: Available features in different L-IOB models

1.3 Scope

This document covers LIOB-18x, LIOB-48x, LIOB-58x, and LIOB-59x controllers with firmware version 8.6 (or higher) and describes specific functions of those device models. Basic device operations are covered in the LOYTEC Device User Manual [1] and data point configuration is covered by the L-INX Configurator User Manual [2]. The usage of logiCAD

itself is beyond the scope of this manual. Please refer to the logiCAD online help in case of additional questions.

2 Disclaimer Cyber Security

LOYTEC offers a portfolio of products, solutions and systems with cyber security functions that enable the secure operation of devices, systems and networks in the field of building automation and control technology. To ensure that devices, systems, and networks are always protected against online threats, a holistic security concept is required that is implemented using the latest technology and is being kept up-to-date. The LOYTEC portfolio is only one component of such an overall concept.

The customer is responsible for preventing unauthorized access to the devices, systems and networks. These should only be connected to a network or the Internet if adequate security measures are in place (e.g. firewalls, separate networks) and a connection is required for operation. In addition, LOYTEC's recommendations for securing devices in the Security Hardening Guide (Chapter 12) must be followed. For additional information, please contact your support person at LOYTEC or visit our website.

LOYTEC is constantly working on improving the existing products in order to follow the latest cyber security standards. Therefore, LOYTEC strongly recommends installing updates as soon as they become available and always using the latest software versions. LOYTEC explicitly points out that using older versions or refraining from updates increases the risk of online security threats, exposing the device to known and documented security threats, which may result in unauthorized access to the device, modification or disclosure of configuration and confidential user data, or disruption of building automation operation. LOYTEC disclaims liability for security incidents, accidents, or failures that are attributable to the use of a product on which available security updates have not been installed.

3 Safety Instructions

	ATTENTION
	General Safety Instructions Please regard the following general instructions for project planning and execution: • Regard all measures or prohibitions of the respective country to avoid danger of electricity and high voltage. • Other relevant regulations of the respective country. • House installation regulations of the respective country. • Regulations of the utility company. • Any specifications, diagrams, dispositions, cable lists and regulations of the customer or system integrator. • Any third-party regulations (e.g., general contractor or client).

	ATTENTION
	Country-specific Safety Regulations Failure to observe country-specific safety regulations can lead to property damage and personal injury. Therefore, comply with the country-specific regulations and the corresponding safety guidelines.

	CAUTION
	Electrical Safety Essentially, electrical safety in building automation systems from LOYTEC is based on the use of extra-low voltage and safe isolation from mains voltage.

	CAUTION
	IEC (SELV, PELV) (world-wide) Depending on the extra-low voltage earthing (24VAC), this results in an application according to SELV or PELV in accordance with IEC 60364-4-41: • Ungrounded = SELV (Safety Extra Low Voltage), • Earth ground = PELV (Protected Extra Low Voltage).

	CAUTION
	NEC (North America) Class 2 transformers with energy limitation to 100 VA or Class 2 circuits with max. 100 VA (using a non-energy-limiting transformer of max. 400VA) combined with overcurrent limits (T-4A fuses) can be used for each individual 24VAC device. Several fuses for several isolated secondary circuits per transformer are possible. The same applies to power supplies with 24VDC.

	CAUTION
	Device Safety Device safety is guaranteed by supply with low voltage 24VAC or 24VDC and a double insulation between mains voltage 230VAC, 24VAC circuits and the housing or by supply via Power over Ethernet (PoE Class 1). In addition, the specific regulations for electrical wiring according to this manual must be observed.

	ATTENTION
	Installation Personnel Only qualified staff may carry out electrical installations.

	CAUTION
	Installation according to Safety Class II LOYTEC devices, which are designed in compliance with safety class II, must be mounted accordingly. The following requirements apply: • Protection against electric shock has to be ensured by an appropriate enclosure. • Ensure proper working cable relief for installation in safety class II equipment.

	ATTENTION
	Environment Conditions LOYTEC devices have to be installed in a dry and clean environment. In addition the permissible environment conditions specified in the product data sheet must be observed.

	CAUTION
	Earth Ground of $\perp$ (System Zero AC/DC 24V) The following items must be observed when earth-grounding system zero $\perp$ 24VAC: • In principle, both earth-grounding and non-grounding of system zero of the operating voltage 24VAC is permitted. Important are the local regulations and customs. Due to functional requirements, earth ground may be necessary or inadmissible. • It is recommended to ground 24VAC systems unless this contradicts the manufacturer's instructions. • To avoid earth loops, systems with PELV may only be connected to earth ground at one point in the system. Unless otherwise stated, usually at the transformer. • The same applies to 24VDC power supplies.

	CAUTION
	Functional Earth ϕ Functional earth must be connected to the building's protective earthing (PE) system on the installation side.

	CAUTION
	Operating Voltage 24V AC/DC The power supply must meet the requirements for SELV or PELV. Permitted deviation of the nominal voltage: • At the transformer or power supply: 24V AC/DC -10 ... + 10% • At the device: 24V AC or DC ± 10 %

	CAUTION
	Specification for 24VAC Transformers IEC: safety transformers according to IEC 61558 with double insulation, designed for 100% duty cycle to supply SELV or PELV circuits. U.S.: Class 2 circuits according to UL 5085-3. For efficiency reasons, the power drawn from the transformer should be at least 50% of the nominal load. The nominal power of the transformer must be at least 25 VA. Using a transformer of smaller size, the ratio of open circuit voltage to voltage at full load becomes unfavorable ($> + 20\%$).

	CAUTION
	Specification for 24VDC Power Supplies Power supplies must be designed for 100% duty cycle to supply SELV or PELV circuits. U.S.: Class 2 circuits according to UL 5085-3. For efficiency reasons, the power drawn from the power supply should be at least 50% of the nominal load.
	CAUTION
	Protection of the 24VAC Supply Voltage Transformers must be protected on the secondary circuit, according to the transformer dimensions and the effective load of all connected devices: Always protect the 24VAC conductor (system potential), Additionally protect the conductor $\perp$ (system zero) where required.
	CAUTION
	Protection of the 24VDC Supply Voltage 24VDC power supplies must be short-circuit proof or have an internal microfuse. Local regulations must be observed.
	CAUTION
	Protection of Mains Voltage Transformers/24VDC power supplies must be protected on the primary circuit using a control cabinet fuse.
	CAUTION
	Power over Ethernet (PoE) LPAD-7 Touch Panels require a PoE Class 1 power supply (max. 12W), which must be compliant to IEEE 802.3at-2009. For the power supply of the PoE switches observe the manufacturer's specifications.

	CAUTION
	Device Installation/Removal in De-Energized State Only Ensure that the power supply is switched off before starting to install or uninstall LOYTEC devices. Do NOT connect or disconnect equipment with power switched on, unless instructed otherwise. Do NOT assemble or disassemble devices with power switched on, unless instructed otherwise.

	CAUTION
	Power Supply Protection When installing LOYTEC devices, ensure that the power source is adequately protected by means of a suitably-rated fuse or thermal circuit breaker.

	CAUTION
	Power Supply Voltage Do not connect a voltage supply greater than the specified maximum rating. Refer to product label and/or datasheet for the correct voltage.

	CAUTION
	DALI is FELV (Functional Extra Low Voltage) A DALI-line is treated to be FELV. Since it is non-SELV the relevant installation regulations for low voltage apply.

	ATTENTION
	DALI Wiring A DALI-line may be installed within the same cable or as single conductors within the same tube as mains supply. The DALI-line is either limited to a maximum length of 300 m using a minimum cross-section of 1.5 mm ² (AWG15) or it must be ensured that the voltage drop on the DALI-line does not exceed 2 V.

**CAUTION****Attention to External Voltages**

Any kind of introduction or spreading of dangerous voltages onto the low-voltage circuits of the system (e.g. due to incorrect wiring) must be avoided at any circumstance and represents an immediate life danger or can lead to the entire or partial destruction of the building automation system.

4 What's New

4.1 New in L-IOB I/O Controller 8.6.0

BACnet Rev 1.26 BTL certified

The BACnet certification of all BACnet models has been updated to comply with protocol revision 26. All new device models are now BTL certified. New BACnet features in that release include

- Network port objects
- BACnet/SC with certificate renewal over BACnet

LDAP User Authentication

The device firmware supports LDAP integration for authenticating users. LDAP users are in addition to built-in and locally defined users. The LDAP configuration defines the LDAP server, bind user/password and user and group queries. Local user roles are mapped to specific LDAP groups. Secure LDAP is also supported.

LDAP server URI *	ldaps://10.101.35.201:636
Use Start TLS	☐
LDAP Server Issuer Certificate	Linux-SVR22DC-CA
Bind DN	cn=ldapbind,ou=Domain Users,DC=linux,DC=local
Bind password	*****
User Search Base *	ou=Linux Users,ou=Domain Users,dc=Linux,dc=local
User Filter	(&(objectClass=person)(objectClass=user)(memberOf=*))
User Name Attribute	sAMAccountName
Group Search Base	cn=Users,dc=Linux,dc=local
Group Search Filter	(objectClass=group)
Group Name Attribute	sAMAccountName
Group Member Attribute	member
LDAP group mapping to local user roles	
superadmin	LDAPsuper
admin	LDAPadmin
operator	
view	

Figure 1: LDAP configuration Web UI.

Zero-Config IP

The default setting on the Ethernet interface is to acquire IP addresses via DHCP. In case there is no DHCP server or the DHCP server is temporarily unavailable, the new zero-config IP feature will assign an IP address in the automatic private IP addressing (APIPA) range 169.254.0.1 to 169.254.255.254. Once assigned this auto-IP address persists over power-on resets. Devices with auto-IP can be found using their mDNS name (i.e. hostname.local).

VNC connection on Web UI

The LCD display on LOYTEC devices can be operated over the network using a VNC connection. The VNC protocol is now available through a websocket URI on the device for so-called ‘noVNC’ clients. This is a secure alternative to the legacy VNC port. The device Web UI offers a simple VNC connect button to open the LCD display content in the web UI using that secure websocket channel.




Figure 2: Secure noVNC popup window on the Web UI.

Node-RED™ 4 and node.js 22

The scripting support on LOYTEC devices has been improved by supporting Node-RED™ 4.1 and node.js 22. This updates the corresponding versions to support the latest palette modules and node.js libraries. The new version now also seamlessly integrates ECMAScript modules in addition to CommonJS format. This makes it easier to integrate modern node.js modules.

4.2 New in L-IOB I/O Controller 8.4.0


Enhanced Account Security and View Role

The built-in user accounts (admin, operator, guest) can be disabled to prevent attacks on those well-known accounts. The admin account can only be disabled, if a custom user account with the superadmin role is created instead. For all accounts, the default settings enforce the use of strong passwords.

The new “view” role has been added that allows a user to view configuration settings only. A view user cannot change any configuration settings.

Responsive Web UI

The Web UI on LOYTEC devices has been enhanced for display on smaller screens such as mobile devices or handhelds. The menu structure collapses in order to save space. Some pages also provide a responsive display to enhance user experience on smaller displays, such as the data point page or Bluetooth commission page.



Name	Value
switch	
lweb900	
glb1_Read	22
glb1_Write	22
glb2_Read	22
glb2_Write	22

Figure 3: Responsive Web UI on the data point page.

Support placeholder %{folder_descr} in Data Point Description

A new placeholder has been introduced that can be used in data point descriptions. The `%{folder_descr}` is expanded to the actual description text set on the parent folder. This can be used to create unique descriptions in CAT instances.

BACnet/SC Node Improvements

The LOYTEC BACnet/SC node has been extended to improve troubleshooting and compatibility with third-party hubs. The node now supports uploading a CA certificate chain. While not required by the standard, this feature gives extra flexibility with certain PKI implementations.

The BACnet/SC node also supports a Wireshark interface, that can be enabled for troubleshooting the encrypted traffic. On the network, IPv6 is supported for hub connections.

Discovery of Devices via loytec.local

Unconfigured LOYTEC devices starting with firmware 8.4.0 can now be easily found without knowing the IP address by simply calling the Web page 'loytec.local'. The search is implemented as an mDNS discovery on the local network. A device finder page is displayed that provides links to all devices found.

Configuration of an Internet Failover Interface

LOYTEC devices can support multiple paths to reach the Internet. For example, Ethernet and an attached LTE-800 interface. For such scenarios, a failover interface can be selected. This failover interface is used as the default route to the Internet, if the primary interface lost Internet connection. This can be configured on the IP Host tab.




Figure 4: Configuration of an Internet failover interface.

Site-to-Site VPN

This special VPN option has been added to make the LOYTEC device a VPN router between sites. While route to local subnet allows access from the VPN to a local node via TCP or

request/response, a site-to-site VPN routes all traffic from local nodes into the VPN. That makes local nodes on network A directly talk to local nodes on network B, where networks A and B are connected via the VPN.

To use this feature, a number of pre-conditions must be met that are not controlled by the LOYTEC device: 1) The OpenVPN server must allocate and push all respective and unique subnets that exist in the site-to-site VPN. 2) Each node on the local network must use a gateway address that directs all non-local traffic to the VPN router. The VPN router delivers the traffic to the VPN.

The screenshot shows the OpenVPN configuration window. On the left, under 'OpenVPN', the 'Site-To-Site' checkbox is checked, while 'TCP/IP', 'FTP', 'Telnet', and 'SSH' are unchecked. On the right, the 'Mode' dropdown is set to 'Client Connection'. Below it, 'Route local subnet' is unchecked and 'Site-To-Site' is checked.

Figure 5: Enabling the site-to-site VPN router.

4.3 New in L-IOB I/O Controller 8.2.0

New generic trend mode “Interval+COV”

Generic trends now offer a new trending mode: Interval+COV. This is a combination of periodic logging and COV trends. Data records are recorded when the COV condition is met and in a periodic fashion.

New historic filter “Current Value”

Historic filters can be configured to use an offset correction data point. In order to process the current value including offset correction, the “Current value” filter item was added. This item contains the offset-corrected value of the underlying data point. It can be used, for example, to trend an offset-corrected meter value after replacing a meter.

The screenshot shows the 'Create Historic Filter' dialog. The 'Name' field is 'OffsetCorrection' and the 'Description' field is empty. Below, the 'Filter Entries' table has two entries:

No.	Name	Type	Day	Time	samples ago
0	Offset	Offset correction	N/A	N/A	N/A
1	Meter	Current value	N/A	N/A	N/A

Figure 6: Current value filter item for offset-corrected historic filters.

Edit BACnet Priority Array on Web UI

The detailed data point Web UI for BACnet objects now offers an editor for the priority array of the underlying BACnet object. The editor allows editing each priority slot, including a clear option to withdraw a slot.




Figure 7: BACnet priority array editor on the data point Web UI.

4.4 New in L-IOB I/O Controller 8.0.0

This section describes the major changes and new features. For a full list of changes refer to the Readme file.

New iCalendar Schedulers

LOYTEC devices support a new scheduler object class that is based on iCalendar events. This scheduler class can be selected as an alternative to the generic scheduler class. It supports extended features such as events that span over midnight or last for several days, flexible recurrence patterns known from Outlook, and booking information. The Web interface has been extended to display an event view of the scheduler. External iCalendar data sources can be imported by using a calendar URL, which allows pulling in data from published Outlook or Google calendars.




Figure 8: New iCalendar scheduler view on the Web interface.

The new `currentEvent`, `upcomingEvent` and `upcomingTime` data points can be used to display booking information of a meeting room, while the `known timeToNext` and `nextEvent` data points allow optimum start algorithms on the controller.

Edge Trigger Mode

Trends and alarms can be based on trigger conditions. There are two new trigger modes available: rising edge and falling edge. These can be used to trigger a recording, if the trigger data point changes from inactive to active (rising) or from active to inactive (falling).

Folder Component Placeholder for Alarm Messages

In addition to the full data point path, individual folder components of the path can now be addressed using the `%{fN}` placeholder, where *N* refers to the *N*-th folder part above the data point. For example on the data point `"/User Registers/Building2/Floor3/Room101/temp"` the placeholder `%{f1}` expands to `"Room101"` and `%{f2}` to `"Floor3"`. This way, individual compositions of the folder components can be assembled to form the alarm message.

New WLAN Configuration Tabs and System Registers

The WLAN configuration of the port configuration has been re-modelled to better match the client and access point (AP) use cases. The tabs are now labelled **WLAN Client** and **WLAN Access Point**. These tabs are restricted to settings that apply to their respective use.




Figure 9: New WLAN configuration tabs

The system registers have also been moved to sub-folders named **WLAN Client** and **WLAN Access Point**. Setting SSID, Key and writing the new Enable system register under either port allows enabling the client or AP, respectively.

BACnet/SC

LOYTEC devices support the BACnet/SC node function. This allows LOYTEC devices to register with BACnet/SC hubs and be integrated in BACnet/SC networks, thus benefiting from increased security including TLS encryption and authentication. On devices with a BACnet router, BACnet/SC can be enabled in addition to or as a replacement of BACnet/IP. Devices without the BACnet routing function can enable either BACnet/SC or BACnet/IP.

The internal device certificate can be used out-of-the-box, and CA-signed operational certificates can be installed as needed. When BACnet/SC and BACnet/IP and/or MS/TP are enabled, the device acts as a router between those interfaces. It is also possible to run BACnet/SC on a separate network than BACnet/IP.




Figure 10: BACnet/SC configuration on Ethernet

Node-RED™ 3.0 and AST for Scripts

The scripting support on LOYTEC devices has been improved by supporting Node-RED™ 3.0. This includes new editor UI features. The underlying node.js has been updated to 18.7. This allows up-to-date palettes and script packages to work on LOYTEC devices.

The API available for node.js scripts has been extended to fully support alarm summaries, alarm acknowledgement, reading and writing schedules, as well as flexible access to historic data in trend logs.

4.5 New in L-IOB I/O Controller 7.6.0

This section describes the major changes and new features. For a full list of changes refer to the Readme file.

Support new LIOB-587/595/596

The new LIOB-587 has the same I/O configuration as the LIOB-586 but adds built-in power measurement functionality on all 6 relay terminals (DO).

The LIOB-595/596 are new models that provide 8 or 6 universal I/O terminals, 4x 2A relays and either a pressure sensor on the LIOB-595 or 2 Triacs (0.5A) on the LIOB-596.

New Structure for System Registers

The system registers have been re-organized under a folder structure. The old system register locations are available for back-ward compatibility. A new system register “Time Zone Name” has been added that allows configuration of the time zone offset and DST settings according to the timezone database. Writing a valid time zone name to that register sets the new timezone information, e.g., “CET” for Central European Time.

Name	Richt.	Typ	Status	Wert
System Time	input	analog	normal	1643298579 s
Time UTC	input	user	normal	"2022 yr" "1 months" "27 d" "15 h" "49 min"
Time Local	input	user	normal	"2022 yr" "1 months" "27 d" "16 h" "49 min"
TZ Offset	input	analog	normal	3600 s
Time Zone Name	value	string	normal	CET

Figure 11: New system register layout.

WiFi Enterprise

To further increase security in a WiFi network, IT departments support the 802.1X authentication method on WiFi also known as WiFi Enterprise. LOYTEC devices can enable WiFi Enterprise in the WiFi settings by selecting WPA2-ENTERPRISE key management. The authentication methods Protected EAP (PEAP), Tunneled TLS (TTLS) and EAP-TLS (using certificates) are supported.

The screenshot shows the 'Wireless' configuration page. On the left, a sidebar lists various protocols: Port Mode, TCP/IP, Wireless (selected), FTP, Telnet, SSH, Global Connections (CEA-852), CEA-709 over IP (CEA-852), LIOB-IP, Web UI, HTTP, HTTPS, VNC for LCD UI, KNXnet/IP, Modbus TCP, Remote packet capture, BACnet/IP, RNI 0 (CEA-709), L-STUDIO, and SNMP. The main area is titled 'Wireless mode: WLAN Client'. It includes fields for SSID (LOYTEC-0000), Search Results (Scan required), Key Management (WPA2-ENTERPRISE), EAP Type (TLS), Identity (testing), CA Certificate (Exampe CA), User Certificate (user@example.org), User Private Key (RSA key (2048 bits)), and Verbose Logging (unchecked). There are 'Delete' buttons next to the CA and User Certificate fields.

Figure 12: Configure WiFi Enterprise

Historic Filters

A new filter item type has been added to historic filters: The Offset Correction item. This item allows correcting the underlying meter value by a given offset. That offset will be added to the measured value before the value is processed by other historic filters. After replacing a meter, the offset correction can be used to maintain continuous consumption.

In addition, historic filter items can now be written to on the Web interface to set historic values. For example, it is now possible to set the value of Jan 1 or any other historic value. On the details page, all historic filter values can be exported to a CSV file. That file can be imported on other historic filter data points allowing the simple transfer of historic values.

Node-RED™ 2.0

The scripting support on LOYTEC devices has been improved by supporting Node-RED™ 2.0. This includes new editor UI features. A new safe mode allows debugging problems in third-party packages.

BTL Testplan 16 Certified

The BACnet certification of all BACnet models has been updated to comply with protocol revision 16. All new device models are now BTL certified. New BACnet features in that release include

- Support Fault_Type and Fault_Parameters in the Event Enrollment object,
- Fault_High_Limit and Fault_Low_Limit properties,
- Support extended “jumbo” MS/TP frames.

4.6 New in L-IOB I/O Controller 7.4.0

This section describes the major changes and new features. For a full list of changes refer to the Readme file.

Support new LIOB-591/592/593/594

The LIOB-591 is a fan coil controller that possesses universal I/O terminals, 4 Triacs (1 x 1250 W, 3 x 300 W), a DALI interface, and an RS-485 port.

The LIOB-592 is a new model that possesses 40 universal I/O terminals and an L-STAT port. The last 12 I/O terminals are internally connected to 12 separate 4-20mA current output terminals.

The LIOB-593 and LIOB-594 are new models that possess 16 or 8 universal I/O terminals, 5x 2A relays, 2x 6A relays and an L-STAT port as well as an MP-Bus port.

New Menu Structure on Web UI

The menu structure on the Web UI has been redesigned to be more intuitive and group frequent actions together. New top-level menus help keeping the menus organized into typical tasks, such as statistics, data viewing, commissioning, configuration, programming, security, and maintenance.

User Management on the Device

LOYTEC devices now provide a simple user management to create users and passwords on the go. Users can be assigned roles, such as 'admin', 'operator' or 'lweb' roles. Users having the 'lweb' role are limited to using LWEB-802/803 visualization projects only and have no other device operation capabilities.

The Web UI on the device allows creating, deleting and modifying users and assigning roles. As an example, an additional admin user can be created who is allowed to configure the device without knowing the master admin password. This user account can easily be disabled again.




Figure 13: User management on the device.

Support for LRS232-802

The new LRS232-802 interface supports two RS-232 ports and is connected to the device's USB port. LOYTEC devices that support the LRS232-802 can be configured to run Modbus ASCII on it or a custom RS-232 serial protocol implemented by a script module. The protocol settings can be found on port tabs under the USB port.

Port 1 Port 2 EXT LIOB **USB** IP Host Ethernet 1 (LAN) Ethernet 2 (WAN) Wireless 1 Wireless 2 Mobile VPN

☐ EnOcean
☐ SMI
☐ MP-Bus
☒ **LRS232**

Save Settings

USB Interface: Connected
Product Name: LRS232-802
Serial Number: 045201000000000032

LRS232 Port 1 LRS232 Port 2

Modbus RTU

Modbus port mode: Master
Baud rate: 38400 (Default)
Parity: None (Default)
Stop bits: Auto
Mode: ASCII
Transmission delay: 0 ms
Slave address: 1 (1...255)

Figure 14: Configure Modbus ASCII on LRS232-802.

Late Linkage of L-IOB Native BACnet Objects

A new feature now allows linking existing BACnet objects as L-IOB native BACnet objects for a given L-IOB I/O as an alternative to the automatic creation of native BACnet objects. This feature is beneficial when using library components with a collection of BACnet objects, that need to be linked to actual I/O configurations when instantiating the library components. This can be easily done on the L-IOB tab by choosing a BACnet object to serve as the native object for an I/O.

Object parameters

Nr	DP Create	OPC	PLC In	PLC Out	Favori...	Parameter name	Parameter value
23						BACnet Object	☒ BACnet Port.Datapoints.MyAI1
24						BACnet Object Type	Analog Input

Figure 15: Link an existing BACnet object as a native BACnet object for an I/O.

BACnet Features for AMEV AS-B Profile and Protocol Rev 1.15

The BACnet implementation now supports additional features to comply with the AMEV AS-B profile. This includes:

- Additional properties for the Loop object,
- new properties for intrinsic reporting, including event and reliability inhibition, alarm message texts config, time delay normal,
- External Notification-B (AE-N-E-B) in the Event_Enrollment object,
- Minimum_On/Off_Time properties for commandable binary objects,
- Min/Max_Pres_Value properties for Analog Value objects,
- Current_Command_Priority for all commandable objects.

Alarming

Both BACnet and generic alarms now support an option to define a different delay for the to-normal transition. Simply select the Time delay normal option and set a delay in the alarm condition dialog. On BACnet, intrinsic reporting and algorithmic reporting facilitate the property Time_Delay_Normal to carry this value. Also, the layout of the alarm dialog has been reorganized to better group the settings by the different alarm transitions.

Figure 16: Option to define a different to-normal delay.

New L-IOB Features

Data points for L-IOB terminal name and description have been added. These allow modification via the data point interface. The I/O description can now also be changed on the L-IOB Web page.

Operating mode "manual disable". This new L-IOB operating mode can be selected to manually disable a terminal. The setting persists an L-STUDIO deploy and cannot be changed over the network until the terminal is manually enabled again.

Spike suppression on pulse counter inputs allows filtering short signal spikes. This feature can be used to de-bounce a contact connected to a pulse counter input.

Network Port Authentication

To further increase security in a network installation, IT departments support the 802.1X port authentication method. This standard requires a device to authenticate its port on the network switch, before traffic into the network is allowed.

LOYTEC devices can enable 802.1X port authentication in the port mode settings. The authentication methods Protected EAP (PEAP), Tunneled TLS (TTLS) and EAP-TLS (using certificates) are supported.

Figure 17: Configure 802.1X port authentication

4.7 New in L-IOB I/O Controller 7.2.0

Support new LIOB-590

The LIOB-590 is a new model that possesses universal analog/digital input/output (IO) terminals, which can be configured as an input to measure resistance, voltage, or current (with or without internal shunt), or as an output to drive a 0-10V voltage output.

Support for LTE

LOYTEC devices now support the LTE-800 mobile interface. This interface is connected via the USB port and offers LTE/UMTS/GSM mobile network access. A SIM card from your provider needs to be inserted and the LOYTEC device is ready on the mobile network. A **Mobile** tab has been added to the port configuration interface for configuring the LTE-800.

Simply enable Mobile Network, enter your APN data and select which protocols shall be run on LTE.

New system registers offer mobile communication statistics such as Bytes transferred or SMS sent. The VPN client is also ready to be used on the LTE mobile network.

Figure 18: LTE-800 mobile configuration

Internet Connection Sharing

Combined with an LTE-800 mobile interface, a LOYTEC device can act as a NAT router to share the mobile Internet connection with other devices on the LAN. For doing so, the **Internet connection sharing** feature can be enabled on the **IP Host** tab, where the default router interface is selected. Other devices on the LAN need to specify the IP address of the LOYTEC device offering connection sharing as their default gateway. This way, local devices can use NTP, VPN client or other Internet services.

Figure 19: Internet connection sharing

Dynamic DNS

LOYTEC devices can now make use of a dynamic DNS service to register a public DNS name. This makes the device reachable over a public IP address that can change over time, for instance an LTE-800 mobile interface using a public IP address assigned by the mobile carrier. A number of dynamic DNS providers are preconfigured and can be selected on the **IP Host** tab of the port configuration as shown in Figure 20.

Figure 20: Dynamic DNS Settings

Secure Building Automation Protocols using VPN

This firmware version enhances flexibility and control over which building automation protocols are directly available on the VPN. A separate **VPN** tab has been added to the port configuration that allows configuring IP-based control protocols to be running directly on the VPN client. This effectively secures otherwise unsecured automation protocols such as BACnet/IP, Modbus TCP, KNXnet/IP or CEA-852. When running on the VPN interface, the protocols are assigned the VPN's IP address and as a protocol node, the LOYTEC device is also reachable over multi-NAT access networks, such as LTE.

For example, simply set up the CEA-852 configuration server on the VPN interface and add all other CEA-852 clients on the same VPN. The same can be done for BACnet/IP. Each node establishes a secure channel to the OpenVPN server hub, which routes the traffic between the communicating peer nodes. No unencrypted traffic will ever be transmitted.

Figure 21: VPN tab on the port configuration interface.

SMS Delivery

The new SMS template message type can be used to configure SMS transmission just like E-Mail templates for E-Mail transmission. SMS can be triggered and contain arbitrary variable text and placeholders. One application is SMS alarm delivery.




Figure 22: SMS template configuration.

SMS can be sent using a locally attached LTE-800 mobile interface or over the network using another LOYTEC device acting as an SMS proxy for its LTE-800 mobile interface. SMS proxy mode can be configured in the new SMS configuration menu on the Web UI. As a result, only one LTE-800 is required to offer SMS service for an entire local network.

Node-RED™ Integration

LOYTEC devices that support the scripting feature now also natively integrate the Node-RED™ run-time. The Web interface provides a configuration menu to open the Node-RED™ editor UI. As a default, the run-time is not executing and needs to be enabled. Once enabled, the run-time automatically starts the configured flows. An example is shown in Figure 23.




Figure 23: Node-RED™ editor UI on the device.

The user can access data points on the device using the pre-installed 'readDP' and 'writeDP' palette items. Custom palette items can also be installed, like the 'worldmap'. The editor UI is also accessible on a stand-alone Web browser page under the '/nodered' device URL.

Parameter and Default Values

A new *Parameter Value* property has been introduced in the data point configuration that tracks the current parameter value on the device. This is in addition to the *Default Value* property. When uploading parameter values from the device into the configuration, the

parameter value property is updated where selected so in the parameter merge dialog. The default value property remains unaffected by a parameter upload. This way it is possible to track current parameter values while still keeping their original default values. When desired, parameter values can be reset to their default values.

Name	Value	Description
Datapoint Path	User Registers.param1	Path to the data point in the hierarchy
Datapoint Type	Double	Class type of the data point
Default Value	☒ 10	Default value when starting up
Parameter	☒	Make available as a parameter
Parameter Value	21	Effective parameter value
Persistent	☒	Make the data point value persistent over power-on resets

Figure 24: The new Parameter Value property.

IPv6

LOYTEC devices now support IPv6 using stateless address autoconfiguration (SLAAC) or having a configured, fixed IPv6 address. The IPv6 feature is available on all Ethernet and WLAN ports. With SLAAC no further configuration (except the required IPv6 router equipment) is required. The static IPv6 address can be configured on the TCP/IP settings on the port configuration.

Protocols that support IPv6 are the Web interface, SSH, HTTPS, NTP and BACnet/IPv6. Additional IPv6 statistics have been added to the IP statistics pages for troubleshooting.

BACnet Dynamic Object Creation and Event Enrollment

New BACnet protocol features have been added to LOYTEC devices. First, dynamic object creation is now supported for Trend_Log, Scheduler, Calendar, Notification_Class objects. This means that a BACnet OWS can dynamically create and delete those objects during run-time. No reserved BACnet objects are required in the data point configuration.

Second, algorithmic reporting has been implemented in the Event_Enrollment object. This object can be created and configured by a BACnet OWS to dynamically add and remove alarm conditions on any BACnet object in the device.

In combination with IPv6 support, the BACnet protocol can be configured to run on the BACnet/IPv6 data link. Simply choose IPv6 in the BACnet/IP protocol configuration.

4.8 New in LIOB-x8x 7.0.0

This section describes the major changes and new features. For a full list of changes refer to the Readme file.

Support two LMPBUS-804

Up to two LMPBUS-804 interfaces can now be connected to the built-in USB ports of the LOYTEC device. This increases the maximum number for supported MP-Bus channels from 4 to 8. Note, that no external USB hubs are supported. The LMPBUS-804 interfaces need to be directly attached to the two built-in USB ports.

Alarming

The data point alarming brings two new features for alarm messages: First, the new placeholders `%{bacName}`, `%{bacDescr}` have been added. These expand to the native BACnet server object name and description. Since these may be updated by an OWS at run-time, alarm messages will now reflect those updates when using the new placeholders.

Another change to alarmed data points are new property relation data points for alarm message texts: msgNormal, msgOffnormal, msgHigh, msgLow, and msgFault. The content of these property data point overwrite the pre-configured alarm messages and can be changed at run-time. This allows easy configuration of alarm messages by linking to common string data points that are parameters. For example, all temperature alarms may link their msgHigh property relation to the string parameter msgTempHigh configured to a local text such as “Temperature %{name} exceeds %{hi}”.

VPN

LOYTEC devices support joining a virtual private network (VPN). This feature is based on the widely-used and open-protocol OpenVPN technology. An OpenVPN configuration file (.ovpn) can be installed on the Web interface and makes the LOYTEC device a VPN client and dial into the OpenVPN server defined by that file. Any standard OpenVPN configuration file can be used, which is auto-login, i.e. does not require entering a password when connecting. After having registered, the LOYTEC device can be reached via its VPN address.

Figure 25: VPN client configuration on the Web interface

Setting up a VPN client on the LOYTEC device may solve NAT router issues, because no port forwarding rules need to be configured. The device dials out to the OpenVPN server running on a public IP and establishes the VPN channel. This VPN channel provides a secure connection for building automation protocols, such as BACnet/IP, Modbus TCP or CEA-852. Being part of a VPN the LOYTEC device is also reachable over multi-NAT access networks, such as LTE.

An alternative method is to enable simple server mode on the LOYTEC device. In this mode, the device provides an OpenVPN server and allows downloading a client configuration file from the Web interface. This file can be installed on any OpenVPN client and allows that client connect to the LOYTEC device over the secure VPN channel. Only one client may connect at a time.

Data Point Web UI

The LOYTEC device is now tracking information on the source of a written value for each data point. This information is shown on the data point details Web UI next to the modification timestamp and can be used for troubleshooting, for example, whether a value was modified over the Web UI or is written by a local connection.

Timestamp	2019-03-27 16:21:43+00:00 written by Web UI
State	normal (0x98000000)
Status description	—
Flags	DEFAULT_VALUE OPC

Figure 26: Write source info on the data point Web interface

Make protocol logs more verbose

LOYTEC devices have been improved to decode protocol logs of its supported technologies to be displayed in a more verbose manner. This makes it easier for Modbus, M-Bus, MP-Bus, SMI, DALI, EnOcean to analyze communication problems with other third-party devices. Simply click the Protocol Analyzer link on the statistics Web page of the respective protocol.

EnOcean over L-STAT

L-STAT devices with EnOcean capability can now be used by LOYTEC devices as remote EnOcean antennas like a LENO-800 interface. This EnOcean over Modbus feature expands the air coverage of EnOcean in a multi-room setup. An EnOcean repeater setup that is cumbersome and difficult to troubleshoot is no longer needed. Simply add EnOcean L-STATs to extend the wireless reach of the LOYTEC device.

BACnet for Japan

This software release includes some minor changes to improve BACnet interoperability in Japan. First, a new client mapping mode was added: COV unsolicited + poll. In this mode the client map not only accepts updates via unsolicited broadcast messages but also actively polls the remote devices. Second, any kind of UnconfirmedEventNotification broadcast (event or alarm) can be used to receive value updates. Third, also status flags of client mappings are updated by event/COV notifications that include status flags.

Support Custom Serial Port in JavaScript

A new API has been added that allows using the serial port on a LOYTEC device in JavaScript. This feature can be used to implement custom serial protocols. The port Web interface offers a choice to select such a custom serial implementation based on meta data provided by the JavaScript module. An example for such custom protocol support is DMX, which is distributed as an add-on script resource.




Figure 27: New Web interface to select custom serial protocols.

Other scripting features added to this release are defining debug filter keywords on the Web interface, enabling and disabling scripts, and a new system API to allow firewall ports on the LOYTEC device.

4.9 New in LIOB-x8x 6.4.0

Localized Web Interface

The entire Web interface of the device has been localized to German, French, and Chinese language. Simply change the language on the LCD display or directly on the Web interface via the new flag symbol on the upper right corner. Changing language is instant and does not require a reboot.




Figure 28: Language selection on the Web interface

Safe Reboot and Auto-Login

Changing IP settings and rebooting could end in a device unreachable, if something was different than expected. The new safe reboot feature helps out by reverting the changes made, if not logged in in on the Web interface within 5 minutes after the reboot. Locking oneself out by entering a mistaken IP address is no longer possible.



Figure 29: Safe reboot screen suggesting new IP address.

Another new feature that helps getting logged in again is the session auto-login. After a device has rebooted the Web interface restores the session and automatically logs in again. Even when changing a static IP address the device tries to connect to the new IP or suggests links for opening the device info page under the new IP address.

Backup before Upgrade

The firmware upgrade feature has been made safer by creating a backup before executing the upgrade. This feature has been added to firmware and Configurator upgrade paths. It is, however, optional and can be turned off by deselecting the check box.




Figure 30: Backup before Upgrade on the Web interface.

Binary Interpretation of Analog Inputs

A simple way to turn an analog universal input (UI) into a digital data point has been added. On the UI select the option **Digital Input** and enter an on/off value hysteresis. A binary data point will be created instead of the analog one.

Support Custom Protocols and IoT by Scripting

The LIOB-585 and upwards L-IOB models now offer a JavaScript-based scripting engine. To activate this feature a separate license (L-IOT1) needs to be purchased. This engine allows users to implement their own protocol support for the IoT world using RESTful APIs, JSON or Web services. The LOYTEC data point server allows integrating data points into the scripting language using the dpal-js API. The script modules can be embedded into and deployed along with the data point configuration.




Figure 31: Web interface for scripting engine

The Web interface of the device offers an overview of installed script modules and allows starting scripts in debug mode. Use the Google Chrome inspector to debug JavaScript on the device. For more information read the new Scripting Chapter in the LINX Configurator User Manual [2].

4.10 New in LIOB-x8x 6.2.0

This section describes the major changes and new features. For a full list of changes refer to the Readme file.

New Models

The L-IOB I/O controller family has been extended by two new programmable models. The new LIOB-588 was especially designed to fit requirements on the U.S market for a roof top unit and a packaged unit. The LIOB-589 was especially designed to fit requirements on the China market for parking garage and water treatment.

L-STUDIO 3.0 with 61131 Run-Time

New L-INX and L-IOB controller models are now embedded into the L-STUDIO workflow using a 61131 program run-time environment. This new environment combines both advantages, the well-known 61131 programming workflow and the powerful mechanisms of L-STUDIO for mass-engineering LOYTEC controllers. Support for the previously used logiCAD run-time and programming tool is also continued for existing products.

LCD Interface

The user interface on the LCD display has been extended by a firmware upgrade menu. This menu allows installing a new firmware image from an attached USB memory stick. This is beneficial for WLAN-only devices. When plugging in a USB memory stick, a menu pops up (Figure 32) on the LCD interface that shows selected quick options, including firmware upgrade and backup.



```
USB Storage Features
Menu >>>>
Firmware Update
Restore
```

Figure 32: LCD pop-up menu for USB storage

BACnet Features

A new BACnet client mapping type has been added: The COV unsolicited type. This new read mapping type, a client mapping will accept broadcast COV updates without subscription.

A new type of BACnet favorites has been added, which offer BACnet-related options such as adding BACnet properties. When linking a BACnet favorite to a BACnet server object, the respective BACnet property data points are added and linked to the link target.

L-IOB Firmware Upgrade and V2 Models

The L-IOB firmware upgrade has been enhanced by a parallel upgrade mode. This mode is back-ward compatible to existing L-IOB devices and allows parallel upgrade over the network. This means a number of devices receive the firmware upgrade at the same time which greatly improves upgrade time over LIOB-FT. This also applies to the new V2 L-IOB models. The Configurator firmware upgrade dialog has also been extended to allow the assignment of a universal L-IOB firmware ZIP archive to all L-IOB models.

Web UI

The data point details page on the Web UI provides write usage information. This information can now be used to determine by which objects a certain data point is being written to. The Web UI design has also been reworked according to the latest security standards, now suggesting usage of strong passwords.

4.11 New in LIOB-x8x 6.1.0

This section describes the major changes and new features. For a full list of changes refer to the Readme file.

Selective Backup and Restore

The backup and restore interface on the Web interface has been extended by content options. It is now possible to decide whether a created backup shall contain passwords, IP settings or historical data (trend logs, alarm logs). Also when restoring a backup archive it can be selected whether password and IP settings shall be accepted from the backup or not. This makes it easier to replicate devices without scarfing the IP configuration and password settings. An example is shown in Figure 33.

The screenshot shows two sections of a web interface. The top section, 'Backup Configuration', has a heading and a sub-instruction: 'Press the backup button to download the current configuration and store it as a file on your computer.' Below this are three checkboxes: 'Include passwords in backup' (checked), 'Include IP settings in backup' (checked), and 'Include trend logs in backup' (unchecked). A 'Backup' button is at the bottom of this section. The bottom section, 'Restore Configuration', has a heading and a sub-instruction: 'To restore a configuration select the backup file (e.g. backup.zip) and press the restore button.' It features a 'Filename' label followed by a file selection button labeled 'Datei auswählen' and the text 'Keine ausgewählt'. Below are two checkboxes: 'Restore passwords' (unchecked) and 'Restore IP configuration' (unchecked). A 'Restore' button is at the bottom of this section.

Figure 33: Backup and restore options on the Web UI.

Flexible Column Layout in Configurator

The Configurator now supports a flexible column layout in the data point list. It is possible to modify the column arrangement and add/remove columns as needed. This provides for better overview in situations where the default column layout misses important information. The new **Configure Columns** dialog makes this possible.

LCD Interface

The user interface on the LCD display has been localized for the Chinese simplified and traditional language sets. The language can be selected from the main page and is switched immediately without a device reboot.

Another feature on the LCD display is the option to rotate the display 180 degrees. This is a useful setting, if the device is mounted upside down.

4.12 New in LIOB-x8x 6.0.0

This section describes the major changes and new features in version 5.0.0. For a full list of changes refer to the Readme file.

New User Manual Structure

The LIOB-X8X User Manual has been split up into three parts: The LIOB-X8X User Manual, which now covers the specific functions of the LIOB-X8X device models. The LINX Configurator User Manual is a common description for using the Configurator software for the L-INX, L-GATE, L-ROC, L-IOB, and L-DALI product line. And the LOYTEC Device User Manual covers hardware, Web interface, LCD display and operating interfaces topics common to all LOYTEC devices.

Flexible CSV Import/Export

The entire CSV import/export engine of the LINX Configurator has been revisited. Previously special export options with fixed columns for CEA-709, Modbus, etc. have been replaced by a general CSV engine that is able to configure columns for any set of data point properties. Default property sets have been added, which can be modified by the user and saved for later use. The new CSV import/export allows modifying existing data point properties by batch edit in Excel or creating new data points. The property sets can be viewed and modified in a comfortable export editor (see Figure 34). The new engine also integrates CSV data point templates. Learn more about this flexible import/export mechanism in the LINX Configurator User Manual [2].




Figure 34: CSV export dialog with configurable columns.

Override Function for Data Points

The data point model in LOYTEC devices has been extended with a manual override function. On the Web interface and on the LCD display data point values can be overridden to manual values. If an override value is set, the running control logic no longer affects the data point value, neither does network communication. The override value is in effect until it is removed again by the user.

Data Point Details	
Path	/User Registers/ValvePos
Name	ValvePos
Description	—
Direction	value
Type	analog
Value	100 % Set Set override Clear override
	Enter "--" for invalid value
Raw value	00 00 00 00 00 00 59 40 Set Set override
	Enter "--" for invalid value
Timestamp	2016-02-19 14:51:38+00:00
State	overridden (0x88000001)

Figure 35: Overriding a data point on the Web interface.

Alarm Messages

The length of alarm messages has been extended to 250. This increased length comes in combination with a new `%{path}` variable placeholder that can identify the data point path in alarm messages. This is beneficial for mass-engineering alarm conditions on data points that have the same name but are located in different path locations. Alarm logs have also been updated to support the new maximum length. BACnet now supports the Event Message Texts property of an alarmed object, which allows retrieving the messages also after a reboot of an alarm client. And analog alarm conditions have been extended to specify a high limit and a low limit alarm message.

Trend Logs

The generic trend logs have been extended to support recording string values. These trends can be operated as polled, COV or triggered. These trend logs can be beneficial to record arbitrary messages. The string recording is currently limited to generic trend logs only.

New E-Mail Placeholders

E-Mail configuration has become even more flexible by adding new variable placeholders. The variable placeholders can be augmented by name, description and path specifiers that expand to the respective information in the e-mail. A new date format specifier allows for readable timestamps and the `%{last_timestamp}` variable expands to the time the last e-mail was transmitted.

BTL Test Plan 12 Certified

The BACnet certification of all BACnet models has been updated to comply with protocol revision 12. All new device models are now BTL certified.

4.13 New in LIOB-x8x 5.3.0

This section describes the major changes and new features. For a full list of changes refer to the Readme file.

Extended Support for U.S. Units

An extended support for U.S. units has been built into LOYTEC devices. A device can now be configured to run either in the SI or the U.S. unit system by defining SI and U.S. units per data point as shown in Figure 36. When configured for U.S. units, all data points and L-IOB I/Os process values in the respective U.S. units. This includes the Web UI, the OPC server, the parameter file, global connections, and logiCAD programs. Also the Configurator displays values in U.S. units and conversions are done automatically. A device can even be switched from one unit system to the other. In this case all persistent parameters are reset to their default values in the chosen unit system. A system register shows the currently running unit system. This makes it easy to entirely engineer a device in U.S. units or build devices that can be configured for either European or U.S. markets and meet local requirements at the same time. For more information on units please refer to the LINX Configurator User Manual [2].

Analog Datapoint Max Value [°F]	☒ 100	Max range of the value
Analog Datapoint Min Value [°F]	☒ 32	Min range of the value
Analog Datapoint Precision	0	Number of significant decimals
Analog Datapoint Resolution [°F]	0	Smallest value increment
Analog Point COV Increment [°F]	5	Change-of-value increment
Unit SI	☒ °C	▼ Data point unit used in the SI system
Unit U.S. (active)	☒ °F	▼ Data point unit used in the U.S. system

Figure 36: Configuration of SI and U.S. units on a data point

Forward Delay in Connections

For applications that require staggered start/stop and randomization, the device implements a configurable forward delay in local and global connections. All received data point items can be configured with a delay. A received value is written to the data point after the delay expires. The delay can be a fixed time or a time interval, in which the actual delay is randomized. With a resolution of 0.1 seconds the total delay can be up to 100 minutes. Learn more about forward delay in the LINX Configurator User Manual [2].

Auto-Generate and Connect

The auto-connect feature has been extended:

- Support `%{folder_descr}` as a placeholder in auto-generate templates. This evaluates the description property of the parent folder.

- Generate into existing connections. Especially when auto-generating the same source data points to different technologies, the same connections are used. This makes it easier to manage auto-generated local connections.

Enhanced Structure Support on the Web UI

The display of data point structures has been improved on the Web UI. The data point listing shows a textual short version of the structured value instead of a hexadecimal Byte buffer. Also CEA-709 structures of NVs without sub-data points are displayed and can be edited.

Project Documentation

A new feature on the device is a Web UI for creating and viewing project documentation on the device. The documentation editor requires admin rights and allows storing files on the device or creating documentation links as URLs. Both items can be viewed by guest users. Examples include storing cabling plans as PDF or adding links to a Web site containing manuals, plans or other useful project documentation. Consult the LOYTEC Device User Manual [1] to learn more about project documentation on the device.

BACnet

All previously extended BACnet features and new features have been BTL-certified in the 5.X firmware series. New features include:

- BACnet object names can be made writeable. With this new option the user can create data point configurations with generic object names and assign location-specific names later in his OWS.
- BACnet simple value objects are now supported. The user can create Large Analog Value, Signed Integer Value, Unsigned Integer Value, Character String Value and Octet String Value objects as needed. Also auto-connect supports these new object types.
- For Trend Log objects, the properties Notify_Type, Event_Enable, Notification_Class can be pre-configured in the data point configuration.

Data Point Creation from CSV Lists

The Configurator implements a new data point template CSV import feature, which can be used by external tools to generate a list of data points. Each line in this CSV references a data point template file that describes all properties of the data point. The CSV supplies name, description and path of the data point to be created. Additionally, data points can be automatically scheduled and trended. Learn more about data point templates in the LINX Configurator User Manual [2].

4.14 New in LIOB-x8x 5.1.0

This section describes the major changes and new features. For a full list of changes refer to the Readme file.

Favorites

Enhancements for using favorites include engineering units, active/inactive texts, multi-state texts and value persistency for unlinked favorites. A new feature are structured favorites. For example, the structure of a SNVT_switch may now be created as a favorite. The top-level part of a structured favorite can be linked to a structured data point of the same type. Alternatively, the individual member elements of a structured favorite can be linked to other, individual data points. This way, one is able to create a structured favorite, that can be linked directly to a matching SNVT or to separate BACnet objects.

Web Interface

The Web interface of the device offers a number of new features:

- A new device info page provides a quick overview of all relevant operational parameters, such as CPU load, active protocols, time synchronization and many more.
- The trend log configuration on the Web UI now also provides a preview tab, which shows a chart of the trend log data. The trend chart allows zoom, scrolling and hiding specific data curves, as shown in Figure 37.




Figure 37: New trend chart on the Web UI

Scheduler

The scheduler objects have been extended by the following new features:

- Color support in BACnet and generic schedulers allows consistent assignment and display of preset colors in L-WEB, L-VIS and the Configurator scheduler UIs.
- Event auto-prune removes passed events, if the capacity of exception events in a scheduler gets low.
- The scheduler default for LONMARK and generic schedulers is extended by a “silent” mode. In this mode the scheduler becomes inactive as soon as the last event is withdrawn. This mode can be used in event-driven scheduler models.
- Generic schedulers allow specifying an existing value preset as the schedule default. LONMARK and BACnet schedulers try identifying a matching preset name from the schedule default value.

Alarm Server Ack-All Data Point

Alarm servers now provide a special ackAll property data point. When writing TRUE on that data point all currently active alarms on the alarm server are acknowledged.

Format Strings in E-Mails

Data point variables used in e-mail templates can now use format strings to specify their numeric appearance in the e-mail text.

Output NVs with Integrated Feedback

Output network variables (NVs) are used to send updates to remote nodes. In order to poll back the actual value of the remote variable, a feedback data point had to be created for the output NV. Now changing the direction on the NV from output to value, an integrated feedback function is activated without the need for an extra data point. This becomes especially useful in data point templates.

4.15 New in LIOB-x8x 5.0.0

This section describes the major changes and new features in version 5.0.0. For a full list of changes refer to the Readme file.

New L-IOB Models

The new models LIOB-484 and LIOB-584 with a 2-port Ethernet switch and a built-in pressure sensor are supported by the firmware. See Sections 13.4, and 13.5.

2-Port Ethernet Switch Support

The new firmware supports all models with a built-in 2-port Ethernet switch. See Section 11.4.

CEA-852 Configuration Server

The LIOB-48x and LIOB-58x models now feature a built-in CEA-852 configuration server.

Duration Mode of Digital Outputs

Digital outputs can be configured in a “Duration” mode. In this mode, the value written to the output is interpreted as a time period, the output shall stay active. When the period ends, the output is automatically switched inactive again.

Support of State-controlled Occupancy Sensors

The L-IOB now also supports occupancy sensors, which do not generate pulses but rather are only switched to the active state as long as occupancy is detected.

Simplified Offset Calibration in the LCD UI

The calibrated life value is now shown next to the offset value for simplified calibration in the LCD UI.

Switching Off Detection of Disconnected Sensors

A new flag is introduced, which allows switching off the detection of disconnected sensors so that every measured value is processed.

Generic Scheduler

Generic schedulers – like generic trends and alarms – can now be created, that are neither CEA-709 nor BACnet objects. Generic schedulers appear next to the generic alarm folder and are ready-to-use on any device. This is beneficial for creating technology-independent

applications. Generic schedulers can write to any technology as well as data point favorites and are the ideal solution, if configured via LWEB-900 only. For more information on creating generic schedulers refer to the LINX Configurator User Manual [2].

Optimum Start for Schedulers

Up to now, optimum start was limited to using a SNVT_tod_event in a CEA-709 scheduler. Now all schedulers (including BACnet and generic schedulers) support timeToNext and nextState data points for implementing optimum start algorithms also for those technologies. Schedulers are extended by property relations, which offer the time to the next state in minutes and the next state in data points. Also, the enable, enableFb (feedback), and presetName information is available as property relations (refer to the LINX Configurator User Manual [2]).

The BACnet scheduler object also has custom properties that expose time to next state and next state to BACnet. If standard BACnet objects are required, the property relations can be linked to any matching BACnet server object as shown in Figure 38 (BV_nextState, AV_timeToNext).

LINX-200 ▶ BACnet Port ▶ Scheduler

Scheduler Name	No.	Direction	OPC	Direction
Schedule_BO_occupied	1	Value	☒	Value
enable	1.1	Value	☒	Value
enableFb	1.2	In	☒	In
nextPresetName	1.3	In	☒	In
nextState -> BACnet Port.Datapoints.BV_nextState	1.4	In	☒	In
presetName	1.5	In	☒	In
timeToNext -> BACnet Port.Datapoints.AV_timeToNext	1.6	In	☒	In
BACnet Port.Datapoints.BO_occupied	1.7			

Figure 38: BACnet scheduler with next state data points.

Favorites

Favorites have been vastly extended to be compatible with all uses that were previously only possible for regular data points. Favorites can now be trended, can have an alarm condition (reporting to a generic alarm server), and be scheduled. Historic filters can be applied to favorites. Favorites can also be used in e-mail templates, math objects and connections like any other data point. Furthermore, it is possible to link favorites to property relations and vice versa, e.g. link a favorite directly to a historic filter data point.

Historic Filters

Historic filters have been extended by a generic delta calculation between any of the defined filter items or the current value. This way, it is no longer necessary to create a separate math object to calculate the consumption of the previous month. Also, a definition for “last day of month” has been added to the monthly period.

Web Interface

The Web interface of the device offers a number of new features:

- Live update of values in the data point list. This allows monitoring values without repeated pressing of reload. Data point structures can be expanded or collapsed for better overview.
- Breadcrumb navigation has been added to the data point list. This gives faster access to sub-folders.

- A new firmware upgrade menu on the Web interface allows online checking for firmware updates and upgrading by selecting a local firmware file. All this is possible without starting the Configurator.
- The trend overview page displays current trend log states and provides controls for easy trend data upload in CSV format.

Data Point Polling

The receive timeout on input and value data points has been generalized. A receive timeout can now be defined on all technologies for input and value data points. Writing updates to those data points from any source (e.g. a global connection) resets the receive timeout.

Background polling can be enabled in the project settings, which allows a slow polling of all data points even if no pollcycle or dynamic polling has been activated on those data points. For more details refer to the LINX Configurator User Manual [2].

BACnet

All LIOB-58x models are now BTL-certified as B-BC devices. Previously extended BACnet features and new features have been BTL-certified in the 5.X firmware series. New features include:

- Intrinsic alarming for the Accumulator object.
- Option to keep OWS settings in BACnet properties also after a new configuration has been downloaded.

Conversion to Value Data Points

Firmware versions since 4.9.0 support value data points. The default behavior of the Configurator can be controlled in the project settings. This defines whether new value data points or the old “_Read/_Write” data point combinations shall be created. When using templates in L-WEB or L-VIS it is often an all-or-nothing approach, a mixture is not practical.

For making the transition in old projects to value data points, the Configurator now offers a conversion tool. Multi-select old read/write data points and choose the item **Convert to value** from the data point context menu. This converts the selected data points to the new value data points, leaving the IDs, default values and data point usages intact.

Application Objects

Application objects such as math objects, e-mail templates, and alarm logs can now be organized in folders. Copy and paste of application objects between Configurators has been improved. Math objects now allow single constants and single variable assignments, such as “=5” or “=v1”. Input variables can be configured to trigger a new calculation or not.

Configurator Usability

The folder tree of the data point manager has been brought to state-of-the-art user concepts such as multi-select, drag-and-drop of folders, moving folders, deleting multiple folders and their contents. A name filter can be applied to quickly find folders in the folder tree.

The property tab has been extended by a property name filter. This makes it easy to find the desired property by typing a sub-string of its name in the filter. For a detailed description on the data point properties refer to the LINX Configurator User Manual [2].

Data point link navigation has been made easy by using a **Go to data point** context menu and speed button everywhere data point references are displayed. A data point usage report dialog shows all references to the selected data point and allows jumping to selected objects.

The new **PLC conflicts** tab shows all PLC write conflicts with other write usage of data points such as math objects, connection receivers, etc., while editing the project. This allows finding problems prior to the configuration download. The conflicts tab also provides easy navigation to data points listed as problematic. For more information refer to Section 8.4.7.

5 Quick-Start Guide

This chapter shows step-by-step instructions on how to configure the L-IOB I/O controller for a simple application.

5.1 Hardware Installation

A LIOB-18x I/O controller is connected to a CEA-709 network using the FT port of the L-IOB device. A LIOB-48x I/O controller is connected to a CEA-852 network using the Ethernet/IP port of the L-IOB device. A LIOB-58x I/O controller is connected to a BACnet network using the Ethernet/IP port of the L-IOB device. In all cases, the device must be powered e.g. using an LPOW-2415A power supply.

5.2 Commissioning or BACnet Setup

For LIOB-18x/48x models, use the appropriate L-IOB template of your LNS™ based network management tool (e.g. NL-220™ or LonMaker™) to create and commission a L-IOB device in the database. Once the device is created, the 'Configure' function of the network management tool can be used to invoke the Configurator Software.

For LIOB-58x models, the initial IP and BACnet setup must be done in the LCD UI or Web UI (see LOYTEC Device User Manual [1]).

The main page of the LCD UI of a LIOB-18x is shown in Figure 39. It displays the device name, project name, Programmable Logic (PLC) status, CPU load, supply voltage, and system temperature. In the row where the CPU load is displayed, there is a language symbol on the right side, where the LCD language can be chosen. In the LIOB-48x/58x LCD UI, the IP address and Ethernet status is shown instead of the PLC status.

Below are menu items. Turn the jog dial to navigate between menu items and press to enter a menu or go into selection mode. When in selection mode, turn the jog dial to alter the value and press again to quit the selection. The **I/O »»** menu is described in the LOYTEC Device User Manual [1]. The **Datapoints** icon (📁) allows browsing through the data points on the device.



Figure 39: Main Screen of the LCD UI

LIOB-48x/58x devices can additionally host one LIOB-45x/55x/56x device in LIOB-IP mode. In this case, there will be an additional **LIOB-IP** menu on the main screen which is described in the LOYTEC Device User Manual [1].

The **Device Settings** icon (⚙️) allows configuring basic device settings. Navigate e.g. to the **Device Management »»** sub-menu, which is displayed in Figure 40.




Figure 40: Device Management Menu on the LCD UI

This menu gives you e.g. the following options for basic device configuration:


- **TCP/IP Setup (LIOB-48x/58x):** IP Configuration page (IP-Address, etc.).
- **CEA-709 over IP (LIOB-48x):** CEA-852 setup page. Here the user can setup the LIOB-48x device to become part of a CEA-852 (CEA-709 over IP) channel. Further settings can be made in the Web interface.
- **Send ID messages:** send out a service pin message (LIOB-18x/48x) or I-Am message (LIOB-58x).
- **Reboot system:** By choosing this item, the device performs a full reboot.
- **Clear DP config:** By choosing this item, the user can clear the device's entire data point configuration.
- **Factory Defaults:** By choosing this item, the user can reset the entire device to its factory default.
- **PIN:** Alter the default PIN to any 4-digit number to protect certain operations on the LCD UI. The user will be prompted to enter the PIN on protected areas.
- **Contrast:** changes the display contrast.
- **Language:** changes the LCD language. Observe that this requires a device reboot.
- **Reset I/O counters:** resets all I/O counters like pulse count values.
- **Device Mode (LIOB-18x/48x):** if switched to "LONMARK Device", the LIOB-18x/48x device is configured to behave like a LONMARK® certified LIOB-15x/45x device, see Section 7.2.

To Set the IP Address on the LCD Display

1. Navigate to the IP address on the main screen and press the button.



2. There navigate to the needed input fields, press and change the value. Press again to set the value. Continue to the next field.



3. Finally navigate to **Save and reboot** and press.
4. Acknowledge the reboot and the device reboots with the new IP address.

To Configure the BACnet Device ID Over the LCD Display

1. On the LCD main screen navigate to **Device Settings »»**.
2. Then navigate to the menu **BACnet »»**.
3. In that menu navigate to the **ID** input for entering the device ID. The field is split into two controls, one for the thousands and one for singles, to simplify entering big numbers.



```
BACnet
Send I-Am message
ID: 0017 800
Name: LIOB-550
Save and reboot
```

4. After the device ID has been entered the device name is automatically assembled using that device ID, if no other name has been configured on the Web UI.
5. To let the changes take effect, the device needs to be rebooted. For doing this now you may select the menu item **Save and reboot**.

5.3 Getting Started With the L-INX Configurator

Before setting up a working IEC61131 program, the data points of the L-IOB device need to be set up. These can be data points of I/Os, network variables, registers, etc. Before executing the steps below, install the L-INX Configurator Software from the 'setup.exe'. This file can be downloaded from www.loytec.com.

To Start a Configurator Project

1. Start the L-INX Configurator software by selecting Windows **Start** → **Programs** → **LOYTEC LINX Configurator** → **LOYTEC LINX Configurator**. The application starts up and displays the data point manager screen as shown in Figure 41.
2. When the device is online, connect to the device by clicking on the LNS or device connect speed button as indicated by the red rectangle in Figure 41.




Figure 41: L-INX Configurator main screen

- For detailed information on how to create data points etc. please refer to LINX Configurator User Manual [2].

5.4 Configuration of the I/Os

The L-INX Configurator uses a separate tab to configure the I/Os. The I/O configuration can be done off-line and is shown in the following steps.

To Configure I/Os

- For LIOB-18x models, select the **Local I/O** tab. For LIOB-48x/58x models, select the **L-IOB** tab and then **LIOB-LOCAL**.



- The I/Os available on that L-IOB device are displayed in the **Inputs / Outputs** table.

Inputs / Outputs

Nr.	TerminalNr	Terminal	Name	Hardware type
1	1	UI1	UI1	IN Analog/Digital
2	2	GND12	GND UI1-UI2	IN Analog/Digital
3	3	UI2	UI2	IN Analog/Digital
4	4	UI3	UI3	IN Analog/Digital

- To adapt the I/O name, double-click the name in the **Name** column and edit it, e.g., 'RoomTemp'.

Nr.	TerminalNr	Terminal	Name	Hardware type
1	1	UI1	RoomTemp	IN Analog/Digital

- Select (or multi-select) an I/O in the **Inputs/Outputs** list and observe the **Object parameters** list below. These parameters can be used to configure the I/O.

Object parameters

Nr	DP Create	OPC	PLC In	PLC Out	Parameter name	Parameter value	Unit	Range	Description
0	☐	☐	☐	☐	Name	RoomTemp			Terminal name
1	☐	☐	☐	☐	HardwareType	IN Analog/Digital			Terminal type
2	☐	☐	☐	☐	SignalType	Voltage 0-10V			Type of the input/output signal

- On the **Datapoints** tab, the data points for the I/Os have been created. These data points can be used, e.g., in the logiCAD IEC61131 program. For inputs the data point L1_x_UIy_**Input** will be used to read an input value and for outputs the data point L1_x_DOy_**Output** will be used to set an output value.

5.5 Getting Started With L-STUDIO

L-STUDIO is the LOYTEC solution for integrated development of PLC programming, data point configuration, visualization and cross-device communication between resources in the runtime. L-STUDIO is used to engineer the entire system, not only single controllers. To fully support integrated cross-cmmunication, the L-STUDIO runtime requires IP-based communication.

For developing IEC61131 programs with L-STUDIO the following components must be installed:

- L-STUDIO setup package. This package installs the L-STUDIO software, which is needed to design PLC programs for the L-INX device.
- L-INX Configurator. This software is required to configure the L-INX device to provide the necessary data points to the PLC and integrate the device into the network.
- L-VIS Configurator. This software is required to create graphics for the CAT (composite automation type). The CAT combines data points, PLC logic, and graphics in one component.
- L-STUDIO runtime license installed on the LOYTEC controller device. Most L-INX devices come with a pre-installed license (see Section 1.2).

The basic components in an L-STUDIO 61131 solution are:

- 61131 program CAT: This contains the functions blocks, data points and sub-function blocks that implement the PLC logic. Logic in the 61131 program CATs is executed on a cyclic basis.
- 61499 CAT: This composite block instantiates one ore more 61131 program CATs and creates the cyclic trigger signal for those blocks.
- Device CAT: This represents a type for the controller equipment on which 61499 CATs can be instantiated. On the device CAT, L-IOB I/Os can be links to favorites that have been generated out of the 61131 CATs.
- Device Resource: This is the physical representation of the controller equipment.

This quick-start guide walks you through the basic steps to create a first simple PLC program in L-STUDIO 61131. For a thorough discussion of the components needed in an L-STUDIO 61131 application the LTRAIN-LSTUDIO training course must be attended. The training material goes into more detail on how to use LOYTEC library components and instantiate CATs for visualization.

To Start an L-STUDIO Project With a 61131 Program

- After installing the necessary software components start the L-STUDIO application from the Windows start menu.

2. Create a new solution in menu **File** → **New** → **Solution...** and enter a name as shown in Figure 42.




Figure 42: Create a new L-STUDIO solution

3. This create a blank solution named 'KickStart' as shown in Figure 43




Figure 43: Blank L-STUDIO solution.

4. Create a 61131 program CAT: In the 'KickStart' solution tree, select **CAT** → **Application**. Then right-click and choose **New Item**. Select IEC61131 CAT, enter a name, and select **Program** as implementation and **Continuous Function Chart**. Then click **Finish** as shown in Figure 44.




Figure 44: Create a 61131 program CAT.

- Open 'MyPGM' and go to the **Configurator** tab. This opens the Configurator for this IEC 61131 program. Create data points as needed, e.g., reg1, reg2, reg_sum. Set **PLC in** on reg1 and reg2 and set **PLC out** on reg_sum as shown in Figure 45. Click on **Save** in the toolbar.




Figure 45: Setting PLC in and out on data points in the Configurator

- Change to the **Program** tab. The created PLC data points show up in the VAR list as shown in Figure 46.




Figure 46: VAR list in the program CAT.

7. In the drawing area below create an 'ADD' function block by Ctrl+W and typing 'ADD'. Right-click on IN1 and select **Add Internal Var**. Type 'reg1' as the VAR name and save. Do the same for IN2 and reg2, and ADD and reg_sum as shown in Figure 47.




Figure 47: Create simple logic in the 61131 program.

8. Click **Save** in the toolbar. This creates a first simple 61131 program. It can be extended by 61131 function blocks.
9. The program CAT is really a 61499 CAT with the TASKIN event as the only input event. It is the “bridge” between the IEC 61499 (outside) and IEC 61131 (inside) programming. It allows to combine IEC 61499 and IEC 61131 functionality in a single device.
10. To embed the program block into the 61499 runtime, create a normal CAT: In the ‘KickStart’ solution tree, select **CAT** → **Application**. Then right-click and choose **New Item**. Select **Normal CAT** and type in a name. Then click **Finish** as shown in Figure 48.




Figure 48: Create a 61499 CAT to embed the 61131 program.

11. Now create a clock signal for IEC61131 programs: Open the new CAT 'MyCAT' and select the **Composite** tab.
12. Create the E_RESTART and E_CYCLE function blocks: This can be done by Ctrl+W and typing E_RESTART as the new element type. That opens a drop-down list as you type. Choose the E_RESTART item and hit Enter. This creates the E_RESTART function block. Repeat this for the E_CYCLE block.




Figure 49: Embed the 61131 program in a 61499 CAT.

13. Connect the COLD and WARM Restart outputs to the START input by drag-and-drop between the function blocks as shown in Figure 49.
14. Right-click on the DT input of the E_CYCLE block, choose **Add Constant** and set it to 'T#100ms'.
15. Delete the lweb block. That block is used only in native 61499 applications and is not used in 61131.
16. Drag and drop the 'MyPGM' block from the solution tree onto the 'MyCAT' composite tab. This creates a program instance. Then connect the EO output to the TASKIN of the program block. Multiple instance of a program are possible. In this case connect the TASKOUT to TASKIN of the next instance.
17. As a next step it is necessary to create a device type. In the 'KickStart' solution tree, select **CAT** → **Application**. Then right-click and choose **New Item**. Select Device CAT, enter a name and choose the device model, e.g. LINX-153, as shown in Figure 50.




Figure 50: Create a new device CAT.

18. Open the device 'MyLinx' and go to the **Composite** tab. Drag the 'MyCAT' from the solution tree onto the composite tab to create a CAT instance (see Figure 51). You may also delete the 'lweb' block as it is not needed.




Figure 51: Create a CAT instance within the device CAT.

19. Finally create a device instance. Open the System  in the toolbar. Then select the **Network** tab. Drag the 'MyLinx' device from the solution tree onto the network tab and assign a name to the device instance as shown in Figure 52.




Figure 52: Create a device instance.

20. Select the **Devices** tab. Then click on the **Device** dropdown and choose **Device CATs...** in order to create the device resources (see Figure 53).




Figure 53: Create device resources in the system.

21. In the list, select all devices that apply and click **Create Devices** (see Figure 54).




Figure 54: Select devices to be created.

22. Edit the IP address, login credentials for the device as shown in Figure 55. Then click **Save** in the toolbar.




Figure 55: Enter IP address and credentials for the device resource.

23. To test click on the **Get status** button as shown in Figure 56. The **Status** column should now show **OK**.




Figure 56: Test connection to the device resource.

24. Deploy the application: Right-click on the device. In the context menu, choose **Deploy** → **Deploy**. The program is compiled and then deployed onto the device.
25. The device will reboot and come up with the new program. Open the Web UI on the device and verify the add function as shown in Figure 57. Note, that two folders have been generated for the two 61131 program instances (MyPGM1, MyPGM2).




Figure 57: Resulting data points on the device.

5.6 Getting Started With logiCAD

For developing IEC61131 programs with logiCAD the following components must be installed:

- L-logiCAD setup package. This package installs the logiCAD software, which is needed to design PLC programs for the device.

- L-INX Configurator. This software is required to configure the device to provide the necessary data points to the PLC and integrate the device into the network.
- logiCAD license for using logiCAD on the PC. The license is available as a softlock version or as a hardlock version with a USB dongle. On virtual machines it is mandatory to use the hardlock license.

A detailed guide on how to install the software components described above and upgrade of an older license can be found in Section 8.2.

To Start a logiCAD Project

1. After installing the necessary software components start logiCAD from the L-INX Configurator by clicking the **Start LogiCAD** speed button.



2. The project wizard starts automatically as shown in Figure 58.




Figure 58: logiCAD project wizard

3. Select **Create new project** and press **Next**.




Figure 59: Available project templates

4. Select the project template for the L-IOB device (e.g. LIOB-18x).




Figure 60: Project name and path

5. Specify the name of the project and the path where to store the project files, see Figure 60.




Figure 61: Additional information

6. After specifying additional information the new project is created by pressing the **Finish** button.
7. As shown in Figure 62 below, expand the tree element **Functionplans** and double click **Plan_1** in order to start editing the plan.




Figure 63: Exposed PLC data points appear in LogiCAD

11. Now the logic can be developed on the function plan.
12. For later debugging, it is good practice to add online test fields to the drawing, to display the current value of the signals during online test. To do this, right-click on the value output of the left function block and select **Create OLT Field** from the context menu, as shown in Figure 64.




Figure 64: Create online test fields

13. Place the fields above and below the drawing as shown in Figure 65, then press the **Save** button to save your changes.




Figure 65: Online Test fields

14. Finally, open the context menu of the **LIOB-18x (48x/58x)** device again and select **Code Generation**. In the dialog, press the button **Start** to start the code generation process. On success, the code generation window reports Errors=0 and Warnings=1.
15. Close the window by pressing the **OK** button. Now the compiled IEC61131 program can be downloaded to the device. Right-click the tree element **LIOB-18x** and select **Download** from the context menu. A connection dialog will appear and ask for the type of connection and additional information.




Figure 66: IEC61131 program download

16. Select the LOYTEC CEA709 communication driver and enter the requested communication settings as described in Section 8.4.2. Start the download process by pressing the **OK** button.
17. After the download completed, check the PLC Status in the LCD display. If it is not “Running”, the logic is not yet running. Reboot the device to start the IEC61131 program.

6 Hardware Installation

6.1 Enclosure

The enclosure of the product and its terminal layout are shown on the installation sheet found in the product's box.

6.2 Product Label

The product label on the side of the L-IOB I/O controller contains the following information (see Figure 67):

- L-IOB order number (e.g.: LIOB-180),
- Date Code, which defines the production week and year,
- Serial number with bar-code (SER#).




Figure 67: L-IOB product label

Unless stated otherwise, all bar codes are encoded using “Code 128”. An additional label is also supplied with the L-IOB for documentation purposes. The specific contents of the product label are shown on the installation sheet found in the product's box.

6.3 Mounting

All L-IOB devices come prepared for mounting on DIN rails following DIN EN 50 022. The devices can be mounted in any position. However, an installation place with proper airflow must be selected to ensure that the L-IOB's temperature does not exceed the specified range (see Section 13.3).

6.4 Power Supply and Wiring

There are four ways of connecting LIOB-18x/48x/58x devices along with all other nodes in a network:

- CEA-709 Free Topology (LIOB-18x),
- CEA-709 Bus Topology (LIOB-18x),
- CEA-852 (LIOB-48x),
- BACnet/IP (LIOB-58x).

All rules of CEA-709 / CEA-852 / LONMARK® devices or BACnet devices regarding network installation, management, and maintenance apply. For using external (non-LOYTEC) power supplies, please refer to Section 11.1. For connecting sensors and actuators to the L-IOB I/Os, please refer to Sections 11.2 and 11.3. The next sections describe the different power supply and cabling variants in detail.

6.4.1 CEA-709 Network Connection in Free Topology

Figure 68 shows the connection of LIOB-18x controllers in free topology, which can be used for cable lengths of up to 500 m between any two devices. As an example for other nodes in the network, a L-INX device is connected on top.




Figure 68: LIOB-18x in Free Topology

The L-IOB devices can either be powered by L-POWs (middle part of Figure 68) or other 24 V power supplies (bottom part of Figure 68). One LT-33 terminator (free topology terminals) must be placed somewhere in the network.

6.4.2 CEA-709 Network Connection in Bus Topology

Figure 69 shows the connection of LIOB-18x controllers in bus topology, which must be used for a cable length of above 500 m. As an example for other nodes in the network, a L-INX device is connected on the top end of the bus. The L-IOB devices can either be powered by L-POWs (middle part of Figure 69) or other 24 V power supplies (bottom part

of Figure 69). An LT-33 terminator (bus topology terminals) must be placed at both ends of the bus.




Figure 69: LIOB-18x in Bus Topology

6.4.3 CEA-852 Network Connection

Figure 70 shows the connection of LIOB-48x controllers over Ethernet/IP. The L-IOB devices can either be powered by L-POWs (middle part of Figure 70) or other 24 V power supplies (bottom part of Figure 70). The L-INX device at the top is an example of a CEA-852 configuration server, which is required in every CEA-852 network.




Figure 70: LIOB-48x Connection

6.4.4 BACnet/IP Network Connection

Figure 71 shows the connection of LIOB-58x controllers over Ethernet/IP. The L-IOB devices can either be powered by L-POWs (top part of Figure 71) or other 24 V power supplies (bottom part of Figure 71).




Figure 71: LIOB-58x Connection

6.4.5 Extension of LIOB-48x/58x Controllers With LIOB-45x/55x/56x Device

The I/Os of LIOB-48x and LIOB-58x controllers can be extended with one LIOB-45x or LIOB-55x/56x device (in L-INX mode) by using the LIOB-IP bus of the controller. Please refer to the L-IOB I/O Module User Manual [4] for how to connect a LIOB-45x/55x/56x device to a L-IOB host (in this case the LIOB-48x/58x controller). The LIOB-585 cannot be extended.

6.5 LED Signals

The L-IOB device is equipped with a three-color status LED which indicates the current state of the L-IOB device. Available LEDs and their location on the respective device model can be found on the product's installation sheet. The installation sheet can be found in the product's box.

6.5.1 Status LED of LIOB-18x

The meaning of the LED signals for the LIOB-18x models is listed in Table 2.

Behavior	Description	Comment
OFF	Online	The L-IOB device is online.
Flickering GREEN	Traffic	The L-IOB device receives or transmits packets.
ORANGE	Manual Mode	At least one I/O is in manual mode.
RED	Error	An error has occurred (e.g. a sensor is disconnected or signals an error).
GREEN flashing at 0.5 Hz	Offline	The L-IOB device is offline.
RED flashing at 0.5 Hz and "LIOB Fallback" shown in LCD UI	Fallback Override	The primary firmware image is corrupt and the L-IOB has booted the fallback image. In this case, the firmware must be upgraded again.

Table 2: Status LED Patterns of LIOB-18x

6.5.2 Status LED of LIOB-48x

The meaning of the LED signals for the LIOB-48x models is listed in Table 3.

Behavior	Description	Comment
GREEN	Online	The L-IOB device is online.
Flickering GREEN	Traffic	The L-IOB device receives or transmits packets.
ORANGE	Manual Mode or no CS	At least one I/O is in manual mode or the configuration server cannot be contacted.
RED	Error	An error has occurred (e.g. a sensor is disconnected or the configuration server has rejected the device).
GREEN flashing at 0.5 Hz	Offline	The L-IOB device is offline.
ORANGE flashing at 0.5 Hz	Offline, no CS	The L-IOB device is offline and the configuration server cannot be contacted.
RED flashing at 0.5 Hz	No CEA-852 Config	The CEA-852 port is not configured. The device must be added to a CEA-852 IP channel.
RED flashing at 0.5 Hz and "LIOB Fallback" shown in LCD UI	Fallback Override	The primary firmware image is corrupt and the L-IOB has booted the fallback image. In this case, the firmware must be upgraded again.

Table 3: Status LED Patterns of LIOB-48x

6.5.3 Status LED of LIOB-58x/59x

The meaning of the LED signals for the LIOB-58x/59x models is listed in Table 4.

Behavior	Description	Comment
OFF	No Traffic	No packets are received or transmitted.
Flickering GREEN	Traffic	The L-IOB device receives or transmits packets.
ORANGE	Manual Mode	At least one I/O is in manual mode.
RED	Error	An error has occurred (e.g. a sensor is disconnected).
RED flashing at 0.5 Hz and "LIOB Fallback" shown in LCD UI	Fallback Override	The primary firmware image is corrupt and the L-IOB has booted the fallback image. In this case, the firmware must be upgraded again.

Table 4: Status LED Patterns of LIOB-58x/59x

6.6 Status Button and Factory Defaults

Some L-IOB models equipped with a status button (see product installation sheet). When pressing the status button shortly during normal operation of the device, a service pin message (LIOB-18x/48x) or I-Am message (LIOB-58x) is sent out, the LCD is reset, and the LCD backlight is switched on.

The status button can also be used to switch the device back to factory default state. Press the button and power-cycle the device. Keep the button pressed until the Status LED illuminates orange permanently. Release the button within five seconds from that time on to reset the device to factory defaults.

On L-IOB models without a status button, use the jog dial instead. Press and hold the jog dial and power up the device. Keep the jog dial pressed until the LCD display prompts you to perform a factory reset. Then release the jog dial within five seconds from that time on to reset the device to factory defaults.

7 Concepts

This chapter describes the basic concepts behind the installation, configuration, and data points of LIOB-18x/48x/58x devices. Observe that not all properties and data points will be available in all configuration instances. Some properties e.g. can only be seen or setup at configuration time, others only at run time.

7.1 Device Installation

For LIOB-58x devices, the first step after hardware installation and IP configuration is to configure the BACnet interface. For LIOB-48x devices, the first step after hardware installation and IP configuration is to add them to a CEA-852 channel. For detailed configuration steps refer to the LOYTEC Device User Manual [1].

The I/Os of LIOB-48x and LIOB-58x controllers can be extended with one LIOB-45x or LIOB-55x/56x device (in L-INX mode) by using the LIOB-IP bus of the controller. Please refer to the L-IOB I/O Module User Manual [4] for how to connect a LIOB-45x/55x/56x device to a L-IOB host (in this case the LIOB-48x/58x controller).

Both the LIOB-18x and LIOB-48x devices must be installed and commissioned like any other CEA-709 / LONMARK® node. Please consult the documentation of your CEA-709 network management tool on how to perform these tasks.

For LNS™ based network management tools, the LOYTEC L-INX Configurator Software acts as an LNS™ plug-in to configure the LIOB-18x/48x devices. It also installs the needed template for the LIOB-18x/48x models when it is registered as a plug-in in the network management software. Both off- and online installation of the L-IOB devices is supported.

For Non- LNS™ network management tools, a LOYTEC NIC such as the NIC-USB100 or NIC852 is needed for configuration of LIOB-18x/48x devices. The devices must be configured (using the CEA-709 connection method of the Configurator Software) before installing and commissioning them in the network management tool.

7.2 LONMARK® Device Mode (LIOB-18x/48x)

LIOB-18x/48x I/O Controllers in a certain configuration are LONMARK® certified. To setup this special configuration, the LONMARK® device mode must be setup in the LCD UI. From the main page choose **Device Settings »» Device Management »» Device Mode** menu and select the mode **LONMARK Device**. The LIOB-18x/48x device will reboot and from now on behave exactly like the corresponding LIOB-15x/45x I/O module in LONMARK® device mode. If e.g. a LIOB-180 device is switched to LONMARK® device mode, it will behave like a LIOB-150 I/O module (in LONMARK® device mode). To switch the device back, go to the device information and configuration page (toothed wheel icon) in the L-IOB LCD UI and switch the device mode back to 'I/O Controller'. Please refer to the LIOB-10x/x5x User Manual [4] for more information about the LIOB I/O modules in LONMARK® device mode.

7.3 Data Point Configuration

Data points are part of the fundamental device concept to model process data. A data point is the basic input/output element on the device. Each data point has a value, a data type, a direction, and a set of meta-data describing the value in a semantic context. Each data point also has a name and a description. The entire set of data points is organized in a hierarchy.

At the data point level, the specific technological restrictions are abstracted and hidden from the user. Working with different technologies at this level involves common work-flows for all supported technologies.

The direction of a data point is defined as the “network view” of the data flow. This means, an input data point obtains data from the network. An output data point sends data to the network. This is an important convention to remember as different technologies may define other direction semantics. If a data point can both receive and send data on the network, its direction is set to value, indicating no explicit network data flow.

The basic classes of data points are:

- **Analog:** An *analog* data point typically represents a scalar value. The associated data type is a *double precision* machine variable. Meta-data for analog data points include information such as value range, engineering units, precision, and resolution.
- **Binary:** A *binary* data point contains a Boolean value. Meta-data for binary data points includes human-readable labels for the Boolean states (i.e., active and inactive texts).
- **Multi-state:** A *multi-state* data point represents a discrete set of states. The associated data type is a signed integer machine variable. Each state is identified by an integer value, the *state ID*. State IDs need not be consecutive. Meta-data of a multi-state data point includes human-readable descriptions for the individual states (state texts) and the number of available states.
- **String:** A *string* data point contains a variable-length string. The associated data type is a character string. International character sets are encoded in UTF-8. A string data point does not include any other meta-data.
- **User:** A *user* data points contains un-interpreted, user-defined data. The data is stored as a byte array. A user data point does not include any other meta-data. This type of data point also serves as a container for otherwise structured data points and represents the entirety of the structure.

7.4 IEC61131 Variables

IEC61131 variables are used to exchange data with the IEC61131 program. These variables are represented in the data point configuration as register data points and can be connected to other data points, e.g. to CEA-709 NV points, via data point connections.

In contrast to CEA-709 variables, IEC61131 variables are always represented as single data point. In case of scalar values (representing CEA-709 scalar or enumeration types) one of the following basic data types might be used:

- **Double:** A register of base type *double* is represented by an *analog* data point. It can hold any scalar value. No specific scaling factors apply.
- **Signed Integer:** A register of base type *signed integer* is represented by a *multi-state* data point. This register can hold a set of discrete states, each identified by a signed state ID.
- **Boolean:** A register of base type *boolean* is represented by a *binary* data point. This register can hold a Boolean value.

Structured IEC61131 variables, representing for example structured NVs, or customer defined IEC61131 structures, are stored as user type:

- **User:** A *user* data point contains un-interpreted, user-defined data. The data is stored as a byte array. A user data point does not include any other meta-data. This type of data point also serves as a container for otherwise structured data points and represents the entire data structure. User data points can only be connected to other user data points of the same data length.

8 IEC 61131

To design the IEC61131 program which should run on the device, the graphical programming tool logiCAD is required. The tool allows creating IEC61131 programs using various IEC61131 programming languages. It offers additional features downloading and debugging of the created program.

In addition to logiCAD, the L-INX Configurator is necessary to create an appropriate data point configuration in the automation server. The usage of logiCAD itself is beyond the scope of this manual. Please refer to the logiCAD online help in case of additional questions.

8.1 Overview

The PLC in the device is intended to perform IEC61131 programs operating on IEC61131 data points. The operating principle is to connect IEC61131 data points to data points derived from CEA-709, BACnet, or L-IOB IOs. Figure 72 depicts the usage of data points for IEC61131 programs at the example of using CEA-709 network variables.




Figure 72: Usage of data points in IEC61131

Alternatively, data points can also be directly exposed as IEC61131 variables. The data points provide a PLC check box for this purpose. In this use case, not special IEC61131 data points are created and no connections are necessary.

8.2 Installing logiCAD

For developing IEC61131 programs with logiCAD the following components must be installed:

1. L-logiCAD setup package. This package installs the logiCAD software, which is needed to design PLC programs for the device.
2. L-INX Configurator. This software is required to configure the device to provide the necessary data points to the PLC and integrate the device into the network.
3. logiCAD license for using logiCAD on the PC. The license is available as a softlock version or as a hardlock version with a USB dongle. On virtual machines it is mandatory to use the hardlock license. How to obtain and install the license is described in this Section.

The L-logiCAD installer installs the IEC61131 programming environment logiCAD and all related software packages. These packages include the template project for the device, the

required software to build IEC61131 programs for the device, and required extensions to interface to CEA-709 networks. Follow the instructions of the installer to install logiCAD.

The language for the logiCAD user interfaces can be set to German or English using the administration folder of the logiCAD control center. The logiCAD control center can be started from the Windows start menu.

8.2.1 Softlock License

The license to run a copy of logiCAD on any PC is based on a softlock license. In case the original softlock license file was generated for an older L-logiCAD version, the software will request an update signature key for the new L-logiCAD installation. This signature key can be found in the file 'logiCAD_Readme.txt' that is located in the installation directory of the L-logiCAD software.

To obtain and install a new license, start logiCAD. The product activation dialog will appear as shown in Figure 73. In this dialog press the button **Download Softlock License**.

Important!

When using Windows 7 or Windows 8, start logiCAD as administrator in order to allow the script read the computer number code. If there are x's in the code, the code was not read by the script.




Figure 73: logiCAD Product Activation

Enter the license data provided with the product information on the Web site form as shown in Figure 74. Fill in the **SL-number** and **Licensing Code** from your L-LOGICAD registration form and click on **Download License File**. Save the license file on your computer or have it e-mailed to you.




Figure 74: logiCAD softlock license Web form

Then install the license using the **Install Softlock License** button in the product activation dialog as indicated in Figure 75.




Figure 75: logiCAD softlock installation

A file requestor dialog opens. Locate the downloaded license file (logiCAD.lf) and click **Open**. Finally click **Close** in the product activation dialog and start logiCAD again. The softlock license is now activated.

8.2.2 Hardlock License

The hardlock license is needed to run a copy of logiCAD in a virtual machine on the PC. It needs to be purchased separately as L-LODICAD-USB and is distributed as a USB hardlock key of type 'CodeMeter'. If no driver for this type of hardlock is already installed on the PC, install the hardlock driver provided on the LOYTEC website. It can be found in Support →

Download and the product selection for L-LOGICAD. After the driver installation has completed, plug in the USB key. It must be recognized as a mass storage device (the details on it show the location 'CodeMeter-Stick'). When starting logiCAD it recognizes the hardlock automatically.

If the driver installation failed, or the USB key was not detected or connected, the window shown in Figure 76 will be shown when logiCAD is started. In this case plug in the hardlock stick, wait for Windows to recognize it and then click **Find Dongle**.




Figure 76: logiCAD Product Activation with Hardlock

Note: logiCAD checks frequently if the USB key is present. When unplugging the USB key, even if logiCAD was successfully started, all major features are automatically disabled. But there is no additional message for the user!

8.3 IEC61131 Project Files

In the L-INX Configurator select the **LogiCAD Files** tab to attach an IEC61131 program and a logiCAD project to the project. The tab is shown in Figure 77.

If there is an IEC61131 program attached to the project, every time a new configuration is downloaded to the device, the L-INX Configurator asks, if the attached program should be downloaded as well. This way, no logiCAD is required to download a suitable IEC61131 program in a separate step. The project designed in the L-INX Configurator can hold all necessary information to set up a running device:

- IEC61131 data point configuration,
- Data point configuration in the device,
- Required connections,
- IEC61131 program.

The logiCAD project directory can also be attached to the configuration file, in order to include the logiCAD project sources from which the program was compiled.




Figure 77: IEC61131 Project Files

To attach an IEC61131 program or a logiCAD project select the file/folder to attach. The selected data will be attached automatically the project. It can be restored to disk by pressing the **Restore to Disk** button. During the development process the attached data may change several times. To update the attached data, located on the before provided path, press the **Refresh** button.

Every time a logiCAD project is successfully compiled, the file MBRTCode.so, the compiled IEC61131 program, is copied to the *public* directory of the device resource for which the program was compiled. Select this file to attach it to the project of the Configurator. Note that the time and date of the file indicates the time of the last code generation. If logiCAD is not able to build a new program, the old file will not be deleted.

The project will be scanned for device resources and the available devices will be listed in the dropdown box called **Device Config**. Select the desired device and press the button **Attach Program** to automatically attach the correct MBRTCode.so file.

8.4 Working With logiCAD

For using the device with logiCAD, a predefined project template for the LIOB-18x/48x/58x must be used. Hence, when creating a new project e.g. for a LIOB-180, select the project template “Project for LIOB-18x”, see Figure 59. For additional information how to create, delete and manage projects please refer to the logiCAD online help.




Figure 78: LOYTEC specific extensions

Figure 78 shows the standard project for the LIOB-18x/48x/58x including all LOYTEC-specific extensions for logiCAD. It shows the structure window showing the project structure on the left, an empty working area top right and the **Error-state viewer** on the bottom right side.

The structure window offers interfaces to the following features:

1. The folder **Functionplans** holds all the program types created within logiCAD. 'Plan_1' is the default plan to start with.
2. The folder **LOYTEC/LIOB-18x** represents the device. The folder **LOYTEC** represents a configuration containing one LIOB-18x/48x/58x resource; please refer to the logiCAD online help for details. To run a program, located in the folder **Functionplans**, a program instance of the corresponding function plan must be created. In the standard LIOB-18x/48x/58x template, a program instance of the 'Plan_1' is already defined. To be able to transfer IEC61131 variables from the device to the IEC61131 program a global variables object within the **LIOB-18x**, **LIOB-48x**, or **LIOB-58x** folder is required, see Section 8.4.1 for details.
3. LogiCAD operates on variable types standardized in the IEC61131 standard. Look for "Elementary and Generic Data Types" within the logiCAD online help to get information about the available data types. For those devices, which are intended to operate on structured NVs, appropriate type definitions for the NVs are required. These definitions are inside the folder **CEA-709_Types**. Additional NVs must be converted to data types that can be processed by logiCAD. Therefore *Technology Converters* are supplied with the project, which perform this conversion. See Section 8.4.3 for details.
4. For designing programs that support the force update functionality (see Section 8.6.1), or designing user-defined *Technology Mapper* (see Section 8.6.2), additional function blocks are required. These blocks are located within the **Loytec_Support** directory.

All LOYTEC-specific add-ons are provided using function blocks. Hence, in the following, all samples are based on designs using function blocks.

8.4.1 Managing Variables

On a function plan, three basic types of variables may be created using the tabs shown below the function plan sheet:

- **VAR:** Variables created on this tab will be visible only to the logic designed on this group of sheets. It will not be accessible to any other programs or to any function blocks which are used in this program. It is similar to a 'static' variable declaration in a C code function.
- **VAR GLOBAL:** Variables declared here will be accessible to the entire program, including any function blocks which are called by the program. Function blocks which need to reference this variable need to have a suitable declaration of an external variable (see next point). This declaration is similar to a 'static' declaration of a C variable outside a function, which will be visible to all functions inside the C code module, but not visible to other modules.
- **VAR EXTERNAL:** Variables declared in this list will be treated as open references to a global variable which exists somewhere in the scope of the device on which the program will be executed. This means that a global variable needs to be declared on the device resource, which will be available to all programs running on the device. If the physical address parameter of the variable is set to %I, %O, or %M, the variable will be handed down to the I/O driver of the device for processing. If a suitable IEC61131 variable exists in the data point configuration of the device, its value will be forwarded by the I/O driver between the PLC variable and the data point. If no physical address is set, the variable will only be visible to the PLC programs but not to the I/O driver, which may be used to exchange data between PLC tasks.

The basic data flow between the CEA709 network (or other technologies) and the PLC program is depicted in Figure 79.




Figure 79: Connecting IEC61131 variables

The place where global variables are created on the device is shown in Figure 80.





Figure 80: Global Variables Object

When starting a new project, no global variables object is available; it must be created before compiling the IEC61131 application. The global variables object is created automatically or manually by the LINX Configurator when exporting variables to logiCAD.



Name	Declaration	Initial value	Longname	Phys.Addr.	Attribute	Type Path	Attached Infor...
switch_input	SNVT_switch			%I		C:\Programme\...	
switch_output	SNVT_switch			%O		C:\Programme\...	

Figure 81: Variables defined in global variables object

Figure 81 shows the contents of a sample global variables object. As shown a global variable is defined by the fields **name**, **declaration** and **phys.addr.:**

- **Name:** The name of a global variable must be unique. The name is used from the IO driver to identify the global variable and from the L-INX Configurator to generate the corresponding IEC61131 data points.
- **Declaration:** Here the type of the global variable is defined.
- **Phys.Addr.:** The IO driver needs to know the data flow direction to be able to update variables. The direction is defined by adding %I for an input variable, %O for an output variable and %M for a marker (input and output). If the address is empty, the I/O driver will not handle the variable, but it may still be used by the tasks running on the device.

Important: *Only ASCII characters can be used for naming the global variables.*

8.4.2 Build and Download the IEC61131 Program

IEC61131 programs, designed using logiCAD, must be cross compiled in order to run on the device. The prerequisite to compile an IEC61131 program are as follows:

- A program instance with associated program type
- A corresponding global variables object

Right click on the LIOB-18x/48x/58x resource, see Figure 80, and select Code Generation. Please refer to the logiCAD online help for the meaning of the options. Take care about the option breakpoint support, see section 8.4.5 for details.

After successfully finished code generation, the IEC61131 application can be downloaded to the device. Right click on the LIOB-18x resource and select download.

The IEC61131 program is downloaded to a LIOB-18x device via CEA-709:

- **CEA-709:** Select the network interface to use and fill out all other fields, see Figure 82. Alternatively, select the network interface and press Auto-detect via Service-Pin. Then press the service pin on the device. Note that this connection method requires an installed LOYTEC network interface.




Figure 82: Connect via CEA-709

The IEC61131 program is downloaded to a LIOB-48x device via TCP/IP or CEA-852:

- **TCP/IP:** Enter the IP address of the LIOB-48x device. Do not change the default communication port (2048). This is the easiest and fastest way to connect to the device.
- **CEA-852 (CEA-709 over IP):** If for some reason, downloading directly via TCP/IP is not possible (e.g. because the required communication port is not accessible over the network), the download can also be done over CEA-852. Select CEA-709 as described above and choose the NIC852 which is a member of the same CEA-852 channel as the LIOB-48x device.

Important: *To be able to communicate with the device via CEA-709 or CEA-852, the device must be commissioned.*

The IEC61131 program is downloaded to a LIOB-58x device via TCP/IP:

- **TCP/IP:** Enter the IP address of the LIOB-58x device. Do not change the default communication port (2048).

8.4.3 Usage of NVs, Technology Converters (LIOB-18x/48x)

To use CEA-709 variables, the content of the NVs must be converted to IEC61131 compliant data types. Look for “Elementary and Generic Data Types” within the logiCAD online help to get information about the available data types. Technology Converters are used to perform the transformation from CEA-709 data types to IEC61131 data types. All Technology Converters are summarized in the subfolder CEA709_Conv located in the StandardLibs folder.

Depending on the type of the NV there are three different ways to use the NV within IEC61131 programs:

- Simple NVs that hold only one scalar value, e.g. SNVT_amp:

Those kinds on NVs are represented as IEC61131 REAL values within logiCAD. There is no additional conversion necessary. Figure 94 shows an example program for scalar data types.

- Simple NVs based on an enumeration, e.g. SNVT_date_day:

The active identifier of the enumeration is represented as Boolean value. When using NVs based on enumerations, Enumeration Converters are used to identify the current state. There are two kinds of Enumeration Converters. First, the Enumeration Converters that convert the enumeration types to Boolean types, grouped in the folder **Convert from CEA709_Enums**. Second, the Enumeration Converters that converts several Boolean inputs to an enumeration type, grouped in the folder **Convert to CEA709_Enums**.

- Structured NVs that consists of a number of fields, e.g. SNVT_switch:

On structured NVs two tasks must be performed by the Technology Converters. First the structure of the NV is mapped to IEC61131 conform data types. Second, if necessary scaling factors are applied. Similar to the Enumeration Converters, the Technology Converters are split up into two subfolders. The first one, which converts the NV into IEC61131 compliant data types, is located in the folder **From_CEA709_Types**. Technology Converters to set up NVs based on IEC61131 data types are grouped in the folder **To_CEA709_Types**.

Figure 83 shows the three possibilities how to use NVs within an IEC61131 program.




Figure 83: Usage of NVs

If a structured NV comprises enumerations types, these enumerations are not split up by the Technology Converter. To get the value of the enumeration, connect an Enumeration Converter to the corresponding output of the Technology Converter.

For every Technology Converter and Enumeration Converter an online help window, displaying the interface description is available. Select the Technology Converter and press F1 to get the interface description.

8.4.4 IEC61131 Program Cycle Time

IEC61131 programs are performed in a periodical manner. IEC61131 tasks are used to control the execution of an IEC61131 program. As shown in Figure 80 several default tasks are defined within the template project. Right click on the clock symbol and select properties to change the cycle time of the task.

As described in Section 8.4 a program instance is required to execute the IEC61131 program. The cycle time of the IEC61131 program is controlled by the task assigned to the program instance. In order to change the cycle time right click on the program instance and select properties. In the upcoming window the task assignment for the selected program type can be changed, see Figure 84.




Figure 84: Task assignment

Please take care when defining names for the tasks. The names displayed in the project view are symbolic names, they do not correspond to the settings for the cycle time, even if the template project use the configured cycle time as task name.

8.4.5 CPU Overload

Several conditions affect the CPU utilization of the IEC61131 program. As a result it is not possible to predict the system load caused by the IEC61131 program. E.g. the following parameters are of particular importance when designing IEC61131 programs:

- Number of inputs and outputs handled by the I/O driver.
- Complexity of the logic in the running IEC61131 program.
- Number of simultaneously running program instances on one device.
- Cycle time of IEC61131 programs.
- logiCAD breakpoint support and force-able code enabled or disabled

The developer of the IEC61131 program is able to check the current system load on the LCD UI. In case of CPU overload, the IEC61131 program may not be able to finish its work within the defined cycle time. Adapt the program in order to reduce the total system load below 80%. Here are a few tips to keep the CPU load down:

- Increase the cycle time, so that the task may finish in time before the next cycle start is scheduled. The PLC kernel will always schedule the next run at an absolute time, no matter how long the previous run took, in order to compensate for irregular execution times and keep a steady cycle time if possible.
- Reduce the number of I/O variables, to reduce the load caused by exchanging data between the PLC program and the data points of the automation server.
- Reduce the number of independent tasks and try to place as much functionality as possible into one task. Every running task will call the I/O driver for new inputs and outputs independently, therefore two tasks running at a 1s cycle time each will cause twice the I/O load of one task running at 1s cycle time.
- Take special care about the complexity of function blocks which are used a lot. Bad performance of one such block may dramatically increase CPU load if it needs to be calculated several hundred times in one cycle.
- Try to disable breakpoint support and force-able code when generating code for the target, to get the most efficient PLC code out of your logic.

- For complex designs, it may be possible to add a state machine using SFC elements and enable/disable large parts of the logic based on the current state of operation.
- Whenever a function does not need to calculate new output values under certain conditions, use the built-in EN input of the block to disable execution and thus reduce the required CPU time, instead of adding your own 'Enable' input which causes the logic to 'behave' as if it would be disabled, while it is actually calculated every cycle. This is similar to power saving methods used in modern electronic devices. Parts which are not required are put into a low power mode instead of keeping them running in an unproductive state.

8.4.6 I/O Driver Settings

Before starting the IEC61131 program, the device performs a check on all defined global variables, which are marked %I, %O, or %M in the physical address parameter. For all variables, which cannot be loaded, because the corresponding data points cannot be located on the device, the I/O driver reports a warning in the system log and shows a listing on the Web interface.

Since IEC61131 program and the data point configuration are downloaded separately, it may be possible that the IEC61131 program does not match the currently active data point interface. In this case it could be dangerous to write values onto those potentially wrong data points. The fact that there are any variables that could not be loaded is taken as an indication for a configuration mismatch. The **I/O check** feature disables the I/O driver of the IEC61131 kernel automatically in this situation. This setting is enabled by default in a new configuration. In the rare case that it is intended to have missing data points, this feature can be disabled in the Configurator. In the system settings de-select the I/O check (see Figure 85). If the I/O driver is disabled, it can be temporarily enabled again on the Web interface until the next reboot.




Figure 85: System settings for I/O check

The project setting **Enforce cyclic output update** enables a cyclic update of output data points, which will ensure that those output data points will contain the calculated value after each cycle. This is the default setting. It can be disabled, if the output data point shall be written only if the calculated value changes. In this mode the output data point can be modified over the Web UI for debugging reasons until the IEC61131 program calculates a new value. This mode can also be used to implement an event-style output operation.

8.4.7 PLC Conflicts

PLC output variables are cyclically updating the respective data points, which are configured as PLC out. If those data points are also written to by other objects (e.g. output of a math object, receiver in a connection) this will not have the desired effect. Also favorites that are PLC out and linked to a PLC out data point will result in two different PLC output variables writing to one and the same data point.

The **PLC Conflicts** tab provides information for detecting such write conflicts on PLC out data points. The tab shows a list of PLC write conflicts and the writing objects, which are in conflict with a PLC out data point. Each reported conflict line can be selected. By clicking the **Go to data point** button  the Configurator navigates to the conflicting object.




Figure 86: PLC conflicts tab.

An example is shown in Figure 86. The user register 'HeatExchangeON_Write' is written to by the PLC, because it is PLC out. But the register is also an output in the math object 'VE01_HeatExchange'. To resolve the conflict, either remove the register from the math object or remove the PLC out check box from the user register. For doing the latter, select the conflict line reporting the register and select **Go to data point**. Then uncheck PLC out on the data point.

8.5 Workflows

8.5.1 Starting With Data Points

This workflow is based on defining data points used for the IEC61131 program in the L-INX Configurator and then export them to logiCAD. Figure 87 presents the basic steps of this workflow. To follow the steps refer to the quick-start description of Section 5.6.




Figure 87: Start with network based information

It is assumed that there are already network data points (CEA-709, I/O, etc.) available. Clicking the Export variables to logiCAD button in the Configurator creates the IEC61131 variables in logiCAD. The following rules are applied in this process:

- The name of the global variables object is derived from the technology base folder (e.g. CEA709, User Registers, etc.). If there is no matching global variables object one is created. If there is already a suitable global variables object, the existing variables are saved.
- There is already a suitable global variables object: If there is an old and new variable with identical name, the type of the variable is checked. In case of a type mismatch of the old and new variable, the old one is discarded and the new one is imported. Additionally a warning is printed on the **Error-state viewer**.
- The name of the global variables object represents the folder name in the L-INX Configurator.

After exporting the data points as global variables to logiCAD, they can be used in the Functionplan 'Plan_1'. To open the respective global variables folder double-click on it. To use the imported variables simply drag and drop the required global variable on to the Functionplan, see Figure 88. The external variables (see Section 8.5.2) are automatically created when adding the global variable to the Functionplan.




Figure 88: Adding global variables to Functionplans

After adding function blocks that perform the expected work, the IEC61131 program is ready to compile and download (see Section 8.4.2).

8.5.2 Starting With logiCAD

This section introduces a workflow how to develop a new IEC61131 program from scratch using logiCAD. Figure 89 shows the necessary steps to perform. For starting a new logiCAD project refer to the quick-start of Section 5.6.




Figure 89: Starting with logiCAD

After creating a new project for a LIOB-18x/48x/58x resource and opening the Functionplan Plan_1 an empty input area is shown, similar to Figure 90.




Figure 90: Start new function plan

The dark gray areas on the left and right side are intended to place the input and output variables, the light gray area is used to place the functional blocks.

As described above, global variables are used to interface IEC61131 data points on the device. As assumed for the current workflow, the IEC61131 data points are created on information based on the global variables exported from logiCAD. Hence, for designing the

program, external variables are used during the design phase. To create a new variable select the **VAR_EXTERNAL** tab, right click in the declaration area and select **New**, as shown in Figure 91.




Figure 91: New external variable

In the upcoming dialog the name and the type declaration of the variable must be specified. The type declaration can be done directly by prompting the type into the declaration field, by selecting the type from the pull-down menu or by drag-and-drop of a specific type from the project tree, see Figure 92. Finally, the new variable is added by pressing the **Add** button.




Figure 92: External variable type declaration

The created variable is added to the declaration area and placed to the drawing area by drag-and-drop. At this time the direction of the external variable is not defined, it can be used as input as well as output variable.




Figure 93: Drag-and-drop external variable to drawing area

Please take care to use an external variable only as input OR output. After adding the external variables to the drawing area, add function blocks to perform the desired actions, see Figure 94 for a sample configuration.




Figure 94: Use external variables

The Functionplan 'Plan_1' represents now a simple program. It adds a defined value to the value of the input variable and sends the result to the output variable.

Add all expected functionality to the 'Plan_1' or use different Functionplans to split up the expected functionality into smaller pieces. But take care about the name and type declaration of external variables when using more than one Functionplan. All external variables with the same name refer to the same global variable.

After adding all functionality, global variables matching the requirements of the defined external variables, must be generated. A tool automatically performs the process of generating the global variables object and the required global variables.




Figure 95: Auto-create global variables

To start the creation of global variables, based on external variables, **Save** all changes, then right click the LIOB-18x/48x/58x device and select **Global Variables** → **Generate**. Then the selected resource is parsed and every program instance found is checked for external variables. In Figure 95 the type instance Plan_1 refers to the Functionplan 'Plan_1', as defined in Figure 94. If there are more Functionplans than the predefined 'Plan_1' appropriate program instances for these plans must be added to the resource before creating the global variables. Anyway, only Functionplans referred from program instances are executed.




Figure 96: Created global variables object

Now there is a global variables object called IEC61131 Variables available, containing all global representations of the external variables defined before. The **Error-state viewer** reports all processed program instances and added variables, see Figure 96 for details.

The global variables are created based on the following rules:

- The direction of the variable is determined based on the graphical representation, shown in Figure 97.




Figure 97: Direction of global variables

Every external variable connected on the right terminal results in a global input variable. External variables connected on the left terminal or on both sides results in a global output variable. Variables connected on both sides can either be used for the force update feature (see Section 8.6.1) or as marker (see Section 8.6.4). As the tool can not distinguish between these two possibilities, per default a global output variable is created.

- If there is already a global variables object, only new variables are added. In case of external variables using the same name as an already existing global variable, the new definition is used and a warning is printed in the **Error-state viewer**.
- In case of two Functionplans, each referring to a global variable with the same name but a different type, the creation process is stopped and an error is printed in the **Error-state viewer**.

Now the IEC61131 program is ready to compile and download, refer to section 8.4.2 for details.

Based on the above created global variables corresponding IEC61131 data points are created on the device. For doing so, start the L-INX Configurator and click the speed button  **Import variables from logiCAD**. Data points are created in the **IEC61131 Variables** folder.

The Configurator reports the results of the import. For the import process the following rules are applied:

- New variables are added

- Variables with same name and type are ignored
- If there are variables with the same name but different type or direction, the variable to import is ignored and a warning is added to the import log.

The name of the folder to import the new variables corresponds to the name of the global variables object. Figure 98 shows the result of the import process.




Figure 98: Connect IEC61131 variables

To create the appropriate network data points for all imported IEC61131 variables select the **IEC61131 Variables** folder and press the button **Generate and Connect Network** <-> **IEC61131 variable from folder**. Check the log output for errors and finally download the configuration to the device.

After rebooting the device, the IEC61131 program is up and running. Check the PLC LED for potential overload.

8.5.3 Pre-compiled IEC61131 Program

In opposite to the last two chapters it is assumed that there are already some components finished, hence starting up from scratch is not suitable. Second, there is the possibility to have an already defined IEC61131 program or an already fixed network interface.

Starting with an already precompiled IEC61131 program results in a similar workflow as presented in Section 8.5.1. The difference is that all logiCAD related tasks are missing. As the IEC61131 program is compiled, the name of the IEC61131 data points is already fixed. The definitions for the data points must be available either in form of a CSV file to import to the L-INX Configurator or as part of a Configurator project. If the network interface for the device was not already defined, the L-INX Configurator can be used to generate and connect the needed data points.

Additionally, there is the possibility that also the network data points are already fixed or that a given, user-defined interface is necessary. Then the developer has to connect the IEC61131 data points to the corresponding network data points by himself.

Finally, after downloading the configuration and rebooting the device, the IEC61131 program can be downloaded to the device via the LINX Configurator. After a final reboot the device loads and executes the IEC61131 program.

8.6 Additional Features

8.6.1 Force Update Functionality

Per default the IEC61131 program only sends updates on changed output values. Every program cycle the input values are fetched, the IEC61131 program is executed and the calculated values are sent to the output driver. If the old values are identically with the new one no updates are sent to the IEC61131 data points. As a result no update is sent to the network.

For some applications, e.g. for a scene controller, it is necessary to send an update on request. E.g. every time the input value is updated, the output value is forwarded to the network, regardless if the value of the output value was changed or not.

For implementing this feature, special vendor blocks are available. First it is necessary to check if there was an update on a selected input within the last execution cycle of the running IEC61131 program. That functionality is offered by the function block Update Notify located in the StandardLibs→Loytec_Support folder. Second, an output must be forced to send an update even if the value was not changed. The function block Force Update is used for that functionality, it is located in the StandardLibs→Loytec_Support.




Figure 99: Force update

Figure 99 depicts how to use the force update functionality. Besides the part of the IEC61131 program that defines the calculations to perform (lower half of Figure 99), additional logic for the force update functionality is required. The global input variable that is monitored for changes is connected to the Update Notification function block. As a result, the Boolean output 'Updated' is set to TRUE for one program cycle, if the value of the connected variable has been updated since the last cycle start. To force the I/O driver send out an update, the global output variable, which shall be updated, is connected to 'Output' of the Force Update block. Hence, every time the 'Update' input of the Force Update block is TRUE, the connected global output variable sends out an update at the end of the program cycle.


Important: *Every global variable connected to the update notification or force update block must be connected via the right-hand side terminal!*

8.6.2 Using UNVT Variables (LIOB-18x/48x)

Similar to the predefined CEA709 data types and the technology converter functions, user-defined network variable data types can be used. The L-INX Configurator supports the developer to generate the type definitions needed for UNVTs and enumerations based on LONMARK resources files.

To Generate Type Definitions for UNVTs in logiCAD

1. Start the L-INX Configurator.
2. Select the menu **Tools** → **Export NV Resource File....**
3. Select the resource file to be exported. Select structured text as format and export the file to a location of your choice by clicking **Export Selected**.



4. To import the created type definition file into logiCAD, add a new library to the project. Right-click on the created library and select **Export/Import** → **Start ST-Import**.
5. Select the file to be imported and check the **Error-state viewer** for the results of the import process.

Using the newly created data types, suitable technology converter function blocks can be created. For each UNVT type, create a normal function block to convert an input of the UNVT type to a number of standard IEC61131 data types and vice versa. You may look at the technology converter blocks for SNVT types which are provided by LOYTEC, to get ideas how to implement your own converter functions.

8.6.3 Create Your Own Data Type

For special applications, custom IEC61131 compliant data types may be created by the user, which do not correspond to any CEA709 network type but should still be available as a data point on the device. Further, such data points can also be made persistent, which makes variables of such custom data types persistent.

Most of the IEC61131 data types may be used as global variables on the device and the L-INX Configurator will be able to create a suitable register data point for the IEC61131 data type. Supported data types include custom enumeration types (a multi-state register with the required states will be created automatically), strings (a string data point with a maximum length of 128 characters will be built), and simple arrays.

While the Configurator will be able to automatically determine the required data point size for simple arrays (like ARRAY [1..16] OF INT) and create a suitable register data point during the IEC61131 variable import, the data size of custom structures cannot be determined automatically at the moment, so the L-INX Configurator does not know how to create a suitable user data point. As a workaround, the type name must contain the desired size of the data point in bytes, for example: MyStructuredType(UT16) will tell the L-INX Configurator to create an IEC61131 register of type 'user' with a length of 16 bytes, to hold the data for the IEC61131 structure defined in the logiCAD program.

8.6.4 Using Persistent Data Points and Markers

Persistent data points are data points on the device that hold their value even after power loss. There is no difference in handling global variables connected to persistent data points or to non-persistent data points. Global variables connected to persistent data points are marked with retain attribute in logiCAD and with the persistent flag in the L-INX Configurator.

Global input variables marked as persistent, supply the IEC61131 program every time with the last received, valid data, even after a power failure. To set an input variable as persistent in logiCAD, open the global variables object containing the appropriate variable, double click the variable, set the **retain** check box and press the **Update** button. Now export the global variables and import them to the L-INX Configurator. After downloading the new IEC61131 point configuration to the device, the data point is set to persistent. Setting the data point persistent in the L-INX Configurator, export the data points and import them to logiCAD is also possible.

Global variables declared as marker can be used as input and output variable in IEC61131 programs. LogiCAD is not able to distinguish markers from global output variables used in combination with the force update feature, see Figure 99. As a result it is not possible to

create a global variables object holding markers automatically. The procedure as described in Section 8.5.1 is not able to decide when to create an output variable or a marker. Markers must be created manually by adding them to the global variables object and setting the physical address to %M.

8.6.5 Using Retain Variables

Retain variables can be used to maintain certain states or parameters of a program over a reboot in those variables, which cannot be kept in persistent data points. Typically, input variables (%I) will be marked as retain variables. For doing so check the **RETAIN** attribute in the variable declaration when creating or editing a variable as shown in Figure 100.




Figure 100: Declaring a retain variable.

The retain attribute should be used in global variables and local variables on function plan only. Global variables on the device resource are managed by the I/O driver and must not use the retain attribute. Instead data point persistency (see Section 8.6.4) must be used for those variables. Furthermore, it is not recommended to mark local variables in function blocks as retain variables.

The contents of retain variables are written to Flash storage every 5 minutes and when shutting down the device. This provides good compromise between write granularity for normal operation and ensuring Flash life-time. If the contents shall be written explicitly at a defined time, use the **RetainCtl** function block located in the **logi.library/Data** folder. Connect the store input (S) and set this input TRUE for one cycle to trigger writing retain data. Make sure to set the input back to FALSE after this cycle to avoid multiple consecutive writes.

8.6.6 System Registers, System Time

System registers, such as the System time or the CPU load, can be used within IEC61131 programs. Therefore, for each system input variable, a global input variable of type UDINT may be created within the IEC61131 program. Then, connections to the appropriate system registers are created manually with the L-INX Configurator.

To use the system time within the IEC61131 program, connect the AtoDT converter (located in the StandardLibs->IEC61131-3_ (EXT) folder) to the global input variable that receives the system time.

8.6.7 Code Protection

There are 4 data points used for code protection. These data points, in combination with an adapted IEC61131 program, can be used to protect your 61131-Program Intellectual Property. Please contact LOYTEC sales for further information.

8.6.8 Using Structured Data Point Members

Some network technologies provide structured data points. Their types are defined by the network technology and are available in the Configurator. Those structure types can either be used in logiCAD by implementing a technology converter (see Section 8.4.3) or by exposing the sub-data points of the respective structures.

To Use Sub-Data Points in logiCAD

1. In the Configurator, expand the structured data point and expose the desired sub-data points of its structure members to the PLC.

Datapoint Name	No.	OPC	Param	PLC	Direction
mod1_Read	1	☒	☐	☐	In
byte_0	1.1	☒	☐	☒	In
byte_1	1.2	☒	☐	☒	In


2. Export the variables to logiCAD. The exposed structure members appear for example as '/UR/mod1_Read.byte_0' in the 'User Registers' global variables block.
3. Export the types for the respective type category in the menu **Tools** → **Manage Structured Types...**. This opens the structured types management dialog.
4. Choose the type **Category**, e.g. 'Modbus'.

Category

5. Click the speed button Save to disk .
6. In the dialog **Export Type to Disk** choose a **Disk Repository Path** and select the extension '.ST' for structured text.

Disk Repository Path 

7. Copy all listed types to the disk repository by clicking . Alternatively select specific types and click . Then click **Save** and exit the dialog.
8. In logiCAD create a new library folder, e.g. 'modbus_types'.
9. Right-click on that new library and select **Export/Import** → **Start ST Import**. In the file dialog choose the previously exported structured text file.
10. The type definitions are now available in the new library.



8.6.9 BACnet Server Objects (LIOB-58x)

BACnet server objects provide additional functionality compared to other network technologies. The most important tasks in an IEC61131 program are:

- Reading sensor data from BACnet input objects,
- writing to commandable BACnet objects with a priority,
- revoking values from commandable BACnet objects,
- handling objects when out of service.

The default data flow direction for a commandable BACnet object (e.g. AO) is input to the PLC (%I). This means its value is commanded over the BACnet network and the logic processes the resulting value. The default for non-commandable BACnet objects (e.g. AI) is output (%O). This means the logic writes the value, which is read out of the object over the BACnet network. With this type of variables the BACnet objects are treated as variables of the IEC61131 program.

When exposing I/Os to BACnet server objects, the BACnet objects represent the I/O values and the IEC61131 program behaves like a user from the network on those objects. Typically sensor values are connected to BACnet input objects (e.g. AI). To read the sensor value the PLC needs an input variable. Since the default data point direction is output, a separate access data point for the PLC must be created. For doing so, use the **Add/Remove BACnet properties** option from the context menu of the data point list and create a read data point for the Present_Value. Figure 101 shows an example, where the PLC uses the input ‘/BAC/AI2.Present_Value_Read’ to get the sensor values from AI2.




Figure 101: PLC with BACnet objects

BACnet output objects (e.g. AO) are connected to actuator I/Os. On those BACnet objects the PLC behaves like a user from the network and needs to write and revoke values at certain priority slots. For writing with a certain priority to a commandable object, a priority write data point needs to be created (see LINX Configurator User Manual [2], Section BACnet Configuration, Write and Read with Priority). This data point is configured with a BACnet write priority in the Configurator and used as an output in the PLC. The example in Figure 101 writes with priority ‘4’ to AO1 over ‘/BAC/AO1_pri4’.

To revoke values in commandable server objects, the **SetValueState** function block must be used. It is located in the **Loytec_Support/Service** folder. The I/O variable of the controlled BACnet object is connected to the **Variable** input of the function block. A Boolean signal needs to be connected to the **Invalid** input. When this input changes to TRUE, the value is revoked at the respective priority slot. When it remains TRUE in the next cycle the service function block is idle. Figure 101 shows an example, how to revoke a value in ‘AO1’ at priority slot ‘4’.

With the out-of-service feature BACnet server objects can be decoupled from the sensor and actuator I/O equipment. When taken out of service, the I/O variables of the PLC are then decoupled from the network. The input variable Present_Value_Read of an AI no longer tracks the sensor value but reflects the value set in the AI from a BACnet OWS. This holds true for all non-commandable BACnet objects. Writing to the priority output variable of an

AO only updates the priority array but no longer drives the actuator. This holds true for all commandable BACnet objects.

The out-of-service state is reflected in the data point status and can be accessed with the **ValueState** function block. This function block reads the value state and is used in a similar fashion as the **SetValueState** function block.

9 Firmware Update

The L-IOB firmware supports remote upgrade over the CEA-709 interface (LIOB-18x), the CEA-852 interface (LIOB-48x), and over IP (LIOB-48x/58x).

9.1 Firmware Update Via the Configurator

The primary image can be updated using the Configurator Software. See the LINX Configurator User Manual [2] on how to install the Software.

To Update the Firmware Using the Configurator

1. Start the Configurator from the Windows Start menu: **Start** → **Programs** → **LOYTEC LINX Configurator** → **LOYTEC LINX Configurator**.
2. Select the menu: **Connection** → **Connect to device** or **Connection** → **Connect via LNS**. See the LINX Configurator User Manual [2] for setting up the connection.
3. In the connection dialog click on **Connect**.
4. Optionally, check for updates by selecting the menu **Help** → **Check for updates**. This function checks for new firmware and Configurator versions.
5. Select the menu: **Firmware** → **Update**.
6. This opens the Firmware Update dialog as shown in Figure 102. Click on the button  and select the firmware image.




Figure 102: Firmware Update dialog of the Configurator

7. Click on **Start** and observe the download progress.
8. When the download is complete, a dialog appears. Click **OK**.
9. In the Firmware Update dialog, click **Close**.
10. The device's firmware has now been successfully upgraded.

9.2 Firmware Update Via the Web Interface (LIOB-48x/58x)

The device's firmware can also be upgraded using the Web interface. This option can be found in the **Config** menu under the **Firmware** item. For more details see the LOYTEC Device User Manual [1].

9.3 Firmware Update Via the USB Port

The device's firmware can be upgraded using a USB memory stick. The LCD display provides a menu to select and perform the upgrade. Select **Device Management »» USB Storage »» Firmware Update** and choose the firmware file. For more details refer to the LOYTEC Device User Manual [1].

10 Troubleshooting

10.1 Technical Support

LOYTEC offers free telephone and e-mail support for the L-IOB product series. If none of the above descriptions solves your specific problem please contact us at the following address:

Delta Intelligent Building Technologies (Europe) GmbH
Blumengasse 35
A-1170 Vienna
Austria / Europe

e-mail : ***support@loytec.com***
Web : ***https://www.loytec.com***
tel : ***+43/1/4020805-100***

or

Delta Intelligent Building Technologies (Canada) Inc.
17850 56 Ave
Surrey, BC V3S 1C7
CANADA

e-mail: ***support@loytec-americas.com***
Web: ***https://www.loytec.com***
tel: ***+1 800.335.8221***

10.2 Remote Packet Capture (LIOB-48x/58x)

Please refer to the Troubleshooting Chapter in the LOYTEC Device User Manual [1] to learn more about packet capture on the LOYTEC device.

11 Application Notes

11.1 External Power Supply (Not Using LPOW-2415A)

When using a non-LOYTEC power supply (see Figure 103), the following rules must be complied with:

- Consistent polarity must be maintained when connecting LOYTEC I/O controllers and modules to the transformer. That is, the ‘- ~’ terminal of each I/O controller and each I/O module must be connected to the same terminal on the secondary side of the transformer.
- The I/O controllers and modules are half-wave rectified. Connecting two half-wave rectified devices to the same transformer without maintaining polarity will cause short circuit.
- The GND terminals of the I/O controller or module are internally wired to the ‘- ~’ terminal. Therefore, if powering I/O controllers and modules with the same transformer, it is again essential to maintain polarity. Failure to do so will result in short circuit and/or damaged device.
- If the transformer output must be grounded, connect the ‘- ~’ terminal to earth ground.




Figure 103: External power supply

11.2 Physical Connection of Inputs

11.2.1 Connection of Switches

On- or off-switches can either be connected to the DIs (Digital Inputs) or to the UIs (Universal Inputs) in digital interpretation.

11.2.1.1 Switch Connected to a DI

A switch can be directly connected to a digital input as shown in Figure 104.




Figure 104: Switch connected to DI

The digital inputs (DI) recognize the following digital signals according to the connected resistance (switch):

Resistance of Switch	Status
$< 6.8 \text{ k}\Omega$	Closed Switch
$> 10 \text{ k}\Omega$	Open Switch

11.2.1.2 Switch Connected to a UI

A switch can be directly connected to a universal input with signal type resistance as shown in Figure 105.




Figure 105: Switch connected to UI

UIs recognize the following digital signals according to the input resistance (switch):

Resistance Switch	Status
$< 1.9 \text{ k}\Omega$	Closed Switch
$> 6.7 \text{ k}\Omega$	Open Switch

11.2.2 Connection of S0 Pulse Devices (Meters)

S0 pulse meters must be connected to digital inputs (DI) as shown in Figure 106.




Figure 106: S0 pulse meter connected to DI

11.2.3 Connection of Voltage Sources to Universal Inputs

The Universal Input (UI) provides voltage measurement both if used as an analog or digital input. The signal type must be configured to 'Voltage 0-10V' or 'Voltage 2-10V' in both cases.

11.2.3.1 Voltage Source Connected to UI With Analog Interpretation

Figure 107 shows the connection of a voltage source to a universal input in analog mode.




Figure 107: Voltage source on UI in analog mode

11.2.3.2 Voltage Source Connected to UI With Digital Interpretation

Figure 108 shows the connection of a voltage source to a universal input in digital mode. In this case, the voltage source acts as a switch with the depicted low and high levels.




Figure 108: Voltage source on UI in digital mode

11.2.4 Connection of 4-20mA Transmitters to Universal Inputs

11.2.4.1 4-20mA Transmitter Connected to UI With Internal Shunt

Some universal inputs have an internal shunt which can be activated (in pairs with another UI) in the Configurator software (signal type 'Current 4-20mA int. Shunt'). Which UIs are equipped with shunts is documented in Section 13.3 and the following Sections. Figure 109 shows the connection of a 4-20mA transmitter to a universal input with internal shunt.




Figure 109: 4-20mA transmitter with internal shunt on UI

11.2.4.2 4-20mA Transmitter Connected to UI With External Shunt

On universal inputs, which do not have an internal shunt, an external shunt must be used as shown in Figure 110. The signal type must be set to 'Current 4-20mA' in the Configurator software.




Figure 110: 4-20mA transmitter with external shunt on UI

11.2.5 Connection of Resistive Sensors

Figure 111 shows the connection of resistive sensors to the universal inputs with a temperature sensor as an example. Sensors in the resistance range of 1 kΩ to 100 kΩ can be measured. The signal type must be set to 'Resistance' in the Configurator software.




Figure 111: Temperature measurement on UI

11.2.6 Connection of STId Card Readers

Figure 112 shows the connection of an STId card reader to three L-IOB inputs (UIs or DIIs). Observe that the clock signal must be connected to an interrupt-capable input of the L-IOB device. More information on STId card readers can be found in the LINX Configurator User Manual [2].




Figure 112: STId card reader

11.3 Physical Connection of Outputs

11.3.1 6A Relays With One External Fuse

The total current of all used 6A relays must be restricted to 6A, if more than two relays share a common (COM) terminal. The wiring shown in Figure 113 can be used for all L-IOB models with common terminals.




Figure 113: 6A relays with one external fuse

11.3.2 6A Relays on LIOB-xx2 Using Separate Fuses

Figure 114 shows the wiring of the 6A relays for the LIOB-182/482/582 models using separate fuses. In this case, two relays share one common terminal (COM).




Figure 114: LIOB-182/482/582 6A relays

11.3.3 16A and 6A Relays on LIOB-xx3

The 16A and 6A relays on the LIOB-183/483/583 models all have two separate terminals per relay. There are no common (COM) terminals. This means that a 16A (or 6A) fuse must be wired to one of the two terminals of each relay, as shown in Figure 115.




Figure 115: LIOB-183/483/583 16A/6A relays

11.3.4 10A Relays on LIOB-586/587

The 10A relays on the LIOB-586/587 models have two separate terminals per relay. There are no common (COM) terminals. This means that a 10A fuse must be wired to either terminal Lx or DOx of each relay, as shown in Figure 116. Note that the N1 terminal must be connected to N for power measurement.




Figure 116: LIOB-586/587 10A relays

11.3.5 6A Relays on LIOB-588/589

The 6A relays on the LIOB-588/589 models have two separate terminals per relay. There are no common (COM) terminals. This means that an 6A fuse must be wired to one of the two terminals of each relay, as shown in Figure 117.




Figure 117: LIOB-588/589 6A relays

11.3.6 External Relays and Inductive Loads

When controlling an external relay or inductive load using a L-IOB relay, either an integrated suppressor circuit must be used for the inductor, or a free-wheeling diode, a varistor, RC circuit, etc. must be installed to suppress voltage peaks and sparking due to switching off inductive circuits. It is recommended to use diodes that are part of the 1N400x family and to place them close to the relay, as shown in Figure 118. Figure 119 shows the connection of a 230V relay with a varistor.




Figure 118: Suppressor circuit with free-wheeling diode




Figure 119: Suppressor circuit with varistor

11.3.7 Triacs

Figure 120 shows the wiring of the 0.5A Triac Outputs.




Figure 120: 0.5A Triacs

11.3.8 Analog Outputs

Figure 121 shows the wiring of the analog outputs (AO). Observe that the analog outputs are labeled '0-10V OUT' but are in fact capable of delivering over 11V.




Figure 121: Analog outputs

The input impedance of the connected load must be greater than or equal to 4.7 kΩ for linear output.

11.4 Redundant Ethernet (LIOB-48x/58x)

11.4.1 Ethernet Cabling Options

Some L-IOB models are equipped with two Ethernet ports, which are connected to an internal Ethernet switch. This allows for advanced cabling options to reduce cabling costs or to increase network resilience. For this discussion, the term *upstream* is used to designate the direction towards the network, which the devices are connected to. Likewise, the term *downstream* is used to designate devices more distant to the network which the devices are connected to.

Redundant cabling options are enabled by the Rapid Spanning Tree Protocol (RSTP) which is implemented in most managed switches. Please note, that this is a feature of the switch, not of the L-IOB device, so that LOYTEC cannot give a guarantee that this will work with a particular switch model. In no case redundant cabling options will work with unmanaged

switches. The older Spanning Tree Protocol (STP) should not be used for this type of application, as it converges too slowly.

Star topology: In the most basic setup, a device is connected to an Ethernet switch with one cable. This is called a star cabling because all devices are connected to a common upstream device. In this setup, the cable and the switch are single point of failures.

Chain topology: Because the L-IOB device itself acts as an Ethernet switch, this device can be connected to a chain. This is a special form of the star topology. Its advantage is the reduced cabling costs. The disadvantage is the connection loss to downstream devices when an upstream device is powered-off, reset or removed. Also, the Ethernet bandwidth (100 MBit/s) is shared among all members of the chain. The last device has one unused Ethernet port, as it is not allowed to create Ethernet loops without STP. The recommended maximum number of daisy-chained devices is 20.




Figure 122: Fully redundant Ethernet topology

Fully redundant topology: Both Ethernet ports are connected to a different upstream switch. Thus, a single cable or upstream switch problem can be tolerated. This topology requires RSTP. In Figure 122, the L-IOB devices with IP addresses 192.168.44.10 to 192.168.44.12 are connected in this way. This connection scheme increases switch and cabling costs, but increases network resilience. Note that the upstream network is connected via the lowest-numbered ports. If this is not possible, the ports need to be configured to the lowest STP port priority value (which is the highest priority).

Ring topology: In this setup, the devices are connected in a chain and each end of the chain is connected to a different upstream switch. This topology requires RSTP. If a single device is powered off, the RSTP will automatically recalculate the spanning tree so that all other devices in the chain are reachable. Only if two devices are power-off at the same time, the devices between them will not have an Ethernet connection. In Figure 123, the L-IOB devices with IP addresses from 192.168.44.10 to 192.168.44.12 are connected in this way. The recommended maximum number of daisy-chained devices is 20.




Figure 123: Ring Ethernet topology

11.4.2 Upstream Options

In case of redundant switches, there are two possible upstream topologies:

Single upstream connection: Switch1 (or Switch2, but not both) is connected to the upstream network while Switch2 only provides a redundant path to the LOYTEC devices. The redundant path is created by a direct Ethernet cable between Switch1 and Switch2 which needs to be plugged into a lower-numbered port than the L-IOB devices are connected to. If this is not possible, the STP port priority for the cross-connection cable needs to be set to a low value. The RSTP domain should be restricted to Switch1 and Switch2. This can be done by enabling a BPDU filter on the port on Upstream Switch 1. This will block all RSTP packets to enter the upstream network. A sample setup for this topology is shown in Figure 124.




Figure 124: Single upstream connection.

Redundant upstream connection: Switch1 and Switch2 are both connected to the upstream network, either to two ports on the same switch or to two redundant upstream switches. In this case, RSTP is needed to ensure a loop-free topology between the upstream switches, Switch1 and Switch2, so the RSTP domain includes the upstream network and the chained L-IOB devices. The configuration of Switch1 and Switch2 need to ensure that they are not selected as the root bridge. If possible device communication should be bound to a separate VLAN and MSTP (Multiple Spanning Tree Protocol) should be employed to isolate the spanning tree operations. This topology is shown in Figure 122.

11.4.3 Preconditions

For the fully redundant and ring topology, the following preconditions have to be met:

- The upstream switches have to support the Rapid Spanning Tree Protocol (RSTP), as defined in IEEE 802.1w.
- The upstream switches have to provide a broadcast storm filter.
- Two distinct switches are required for each end of the device chain.
- Both upstream switches are connected to the same Ethernet network.

11.4.4 Switch Settings

The switches which connect the devices to the network need the following settings. Note that these are only recommendations or starting points. Each network with redundant connections needs testing and verification to prevent network loops.

- The STP bridge must be enabled.
- The STP bridge priority should be set to the minimum (61440), so that these switches are not elected as root bridges.
- The bridge mode should match the upstream bridge modes, preferable 802.1s or 802.1w.

If the upstream network uses RSTP, the timing parameters of the upstream networks must be used. Else the timing parameters should be set to minimum values for fast convergence:

- Bridge max age time: 6 seconds
- Hello time: 1 seconds
- Forward delay: 4 seconds
- All ports connected to Ethernet rings have to be configured as NON-EDGE ports, so that the RSTP can detect loops
- The switches should be configured to block broadcast storms. A recommended rate is 5% or 3000 packets/seconds.

The upstream switches need the following configuration:

- If a single upstream connection is used, the connected port on the upstream switch should have BPDU filtering enabled.
- If redundant upstream connections are used, the connected ports on the upstream switches should have a BPDU root guard enabled.

11.4.5 Testing

When the switches are configured and the devices are connected, the following tests are recommended. These tests are important to confirm that the STP changes due to topology changes to not interfere with the rest of the network.

- Check that no broadcast storms are sent into the upstream network by capturing traffic between Switch1, Switch2 and the Upstream switch. This test should be done continuously, especially during switch and device power cycles.
- Check that all devices can be reached (ICMP ping).

Execute these tests for these conditions:

- Power up all switches and devices. Wait until all devices are up, then test.
- Power-off Switch1. Wait approx. 10 seconds, then test.
- Power-on Switch2, power-off Switch1. Wait until Switch2 has booted, then test.
- Power-on Switch1. Wait until Switch1 has booted, then test.
- Reboot all L-IOB devices. Wait until the devices have booted, then test.
- Remove a single Ethernet cable. Wait approx. 10 seconds, then test. This test should be repeated for different cables. Make sure that at least the following connections are tested:
 - The connection between Switch1 and the L-IOB device directly connected to Switch1.
 - The connection between Switch2 and the L-IOB device directly connected to Switch2.
 - A connection in the middle of the chain, which is not connected directly to either Switch1 or Switch2.

11.4.6 Example Switch Configuration

The following example shows the configuration commands for Switch1, Switch2 and the upstream switch (HP Procurve syntax) in the setup shown in Figure 122.

Upstream switches:

```
config
spanning-tree
spanning-tree priority 8
spanning-tree 3,4 root-guard
spanning-tree hello-time 1
spanning-tree forward-delay 4
spanning-tree maximum-age 6
exit
```

Switch1 and Switch2:

```
config
spanning-tree
spanning-tree priority 15
spanning-tree 1,2 port-priority 0
spanning-tree 3-5 port-priority 8
spanning-tree hello-time 1
spanning-tree forward-delay 4
spanning-tree maximum-age 6
exit
```

12 Security Hardening Guide

This guide contains security-relevant information for operating the LIOB-48x/58x/59x on IT networks. The information refers to the firmware version and the instructions found in the previous chapters of this User Manual.

12.1 Installation Instructions

Install the device over the Web interface:

- Set up the basic device functions and protocol settings as described in Chapter 5. When connecting over the Web UI use https:// in the URL.
- Set a secure password for the admin and operator accounts.
- Disable the HTTP, FTP, and Telnet servers in the IP port configuration as described in the LOYTEC Device User Manual [1]. Note, that FTP and Telnet are disabled in factory defaults as of firmware 7.0.0.
- Create a new HTTPS server certificate as described in the LOYTEC Device User Manual [1].
- Set a password for the “guest” user to protect information of the device info page from unwanted disclosure.

12.2 Firmware

The device is equipped with one piece of software. This is the firmware image and its related firmware version. The firmware is distributed as a downloadable file. The device can be upgraded by placing the firmware image onto the device using the procedure described in Chapter 9. The device firmware is signed by LOYTEC and its signature integrity is verified before the upgrade is allowed.

Firmware Upgrade Cyber Security Disclaimer

LOYTEC regularly releases firmware updates that address security vulnerabilities. Failing to install a security update leaves the device exposed to known and documented security threats, which may result in unauthorized access to the device, modification or disclosure of configuration and confidential user data, or disruption of building automation operation. LOYTEC disclaims liability for security incidents, accidents, or failures that are attributable to the use of a product on which available security updates have not been installed. It is the explicit obligation of the user to install any security updates promptly as soon as published by LOYTEC.

12.3 Ports

This Section lists all ports, which may be used by the device. The ports are default settings for their respective services. If not stated otherwise, the ports can be changed.

Required Ports:

- 443 tcp: This port is opened by the Web server and the OPC XML-DA server. It offers secure communication. Make sure the L-STUDIO deploy method is set to “loytechhttps” and the Configurator as well as other clients use secure connection.
- 1628 udp/tcp: This is the data exchange port for CEA-852 (LON over IP). It is required for the primary function of the device to exchange control network data between routers over the IP network. Each device needs this port open. The port can be changed.
- 47808 udp (LIOB-58x): This is the data exchange port for BACnet/IP. It is required for the primary function of the device to exchange control network data between routers over the IP network. Each device needs this port open. The port can be changed.

Optional ports not necessary for the primary product function. They can be disabled as described in the installation instructions in Section 12.1:

- 21 tcp: This port is opened by the FTP server. The port can be changed and disabled.
- 22 tcp: This port is opened by the SSH server. The port can be changed and disabled.
- 23 tcp: This port is opened by the Telnet server. The port can be changed and disabled.
- 80 tcp: This port is opened by the Web server and the OPC XML-DA server. It should be disabled and HTTPS (port 443) be used instead. The port can be changed.
- 161 tcp: This port is opened by the SNMP server. This port is disabled by default. The port can be changed.
- 5900 tcp: This port is opened by the VNC server, if it is enabled. This port is disabled by default. The port can be changed.
- 502 tcp: This port is opened, if Modbus TCP is configured in slave mode. This port is disabled by default. The port can be changed.
- 3671 udp: This port is opened by KNXnet/IP, if KNX is enabled on the Ethernet interface. This port is disabled by default. The port can be changed.
- 1630 udp/tcp: This port is used by the CEA-709 RNI and for the remote LPA. The port can be changed and disabled.
- 2048 tcp: This port is opened by the logiCAD online test. It cannot be changed. The service can be disabled but the port will remain open.
- 16028/16029 udp: These ports are opened for LIOB-IP on the device. These ports cannot be changed. They can be disabled.
- 2002 tcp: This port is opened by the Wireshark protocol analyzer front-end. This port is disabled by default. The port can be changed.
- 4840 tcp: This port is opened by the OPC UA server. This port is disabled by default. The port can be changed.
- 5353 udp: This port is open for finding the device using mDNS names such as loytec.local. This port can be disabled.
- 1900 udp: This port is open for the SSDP discovery service. It cannot be disabled.
- 61000-62299 udp: This port range is used for IEC-61499 cross-communication between controllers. The ports are assigned automatically by the L-STUDIO programming tool.

12.4 Services

Required services:

- CEA-852 (LON over IP): Primary function of the device. This service is in accordance with the standard ANSI/CEA-852-B.

- BACnet/IP (LIOB-58x): Primary function of the device. This service is in accordance with the standard ANSI/ASHRAE 135-2010.
- OPC XML-DA: This Web service provides access to data points over the OPC XML-DA standard.

Optional services not necessary for the primary product function. They can be disabled as described in the installation instructions in Section 12.1:

- mDNS: This service is used for finding the device via multicast DNS in order to establish initial communication. This allows using DNS names such as loytec.local in the Web browser. This service can be disabled.
- HTTP: Web server. It provides a Web-based configuration UI. The Web UI can be disabled after setting up the device.
- HTTPS: Secure Web server. It provides a Web-based configuration UI using HTTPS. It is also used for a secure Configurator connection.
- SSH: SSH server. It provides secure access to the device console menu over the network.
- FTP and Telnet: The FTP and Telnet server is used for connection to the device by the Configurator for configuration, firmware upgrade, and access to the log file. On devices without SSH these services must be enabled during device configuration.
- VNC: The VNC server can be used for remote access to the LCD display on devices that have it. The service is disabled by default.
- Modbus TCP: A Modbus TCP server is running when Modbus TCP is operated in slave mode. In all other cases this service is not needed.
- KNXnet/IP: A KNXnet/IP server is running if KNX is enabled on the Ethernet port. In all other cases this service is not needed.
- RNI: This service provides the remote network interface (RNI) function. It is also used by the remote LPA feature. If these features are not needed the service can be disabled.
- logiCAD online test: This service is used by the L-logiCAD programming tool for online debugging of IEC61131 programs. It is enabled by default. The service can be disabled.
- LIOB-IP: This service is used by the L-IOB host function to operate LIOB-IP I/O modules. This service is enabled by default on all L-INX devices. The service can be disabled.
- OPC UA: This secure service provides access to data points over the OPC UA standard. The service is disabled by default.
- SNMP: SNMP server. It provides network management information on the device used by standard IT tools. The service is disabled by default.
- Wireshark front-end: The Wireshark protocol analyzer may connect to this service and retrieve online protocol analyzer logs. The service is disabled by default.

12.5 Upgrade Key Strength

The secure services (HTTPS, SSH) rely on certificates to authenticate the device against the connecting client. This is key to prevent man-in-the-middle attacks. The device comes with pre-installed server certificates. It is recommended to upgrade the pre-installed certificate to an individual server-certificate and use stronger key length.

- Server certificate (for HTTPS, OPC UA): Follow the instructions in the LOYTEC Device User Manual [1] Section 3.2.29 Certificate Management on how to upgrade the pre-installed X.509 server certificate to a custom, self-signed or CA-signed certificate with stronger key length.

- SSH key upgrade: If SSH is enabled it is recommended to upgrade the SSH key length. Refer to the LOYTEC Device User Manual [1] Section 3.2.28 SSH Server Config on how to upgrade your RSA key to 2048 bits.

12.6 Logging and Auditing

The device contains a log file, which can be read out over SSH or the Web server. This log contains information when the device started and when crucial communication errors occur. Other information such as user log-on are not logged as they are not part of the primary services of this device.

Logged events:

- Time of the last power-on reset of the LOYTEC device.
- Time and version of the last firmware upgrade.
- Time when the device configuration has been cleared or the device was reset to factory defaults.
- Commission of the CEA-709 node.
- Static errors in the device and data point configuration.
- System overload situations as one-time log messages since last power-on.
- Crucial communication errors as they occur.
- Logins and login failures.
- Failed firmware upgrade attempts.

12.7 Network Access

Network access can be protected by using 802.1X port authentication (as of firmware 7.4.0) using EAP-TLS, PEAP, or TTLS. Unused Ethernet ports can be disabled.

12.8 Password Protection

Devices provide separate administrative (admin) and operative (operator) user accounts. Passwords are not stored, only a strong cryptographic hash (salted SHA256) thereof. Device login is protected by a login trap that blocks logins for 10 seconds after ten consecutive failed login attempts using different passwords to protect against brute-force password attacks. Initial password setting is enforced to use strong passwords. Without setting the initial password, the device functionality is locked down. Passwords can be up to 64 characters long and contain any printable UTF-8 character.

To protect usage of the admin password, the admin user can create additional user accounts with an admin role. Those additional user accounts can be disabled as needed. Usernames can be up to 32 characters. The built-in user accounts can be disabled, if custom user accounts with those roles have been created.

12.9 Encryption-At-Rest

Client credentials required for operation (e.g., E-Mail client) are stored in encrypted storage using AES256-CBC with nonce. The secret encryption key is bound to the device and cannot

be accessed or read out of the device. Credentials can be exported or imported encrypted by a project password and PBKDF-2.

12.10 Secure Disposal and Decommissioning

Before disposing of, reselling, or returning a LOYTEC device, the user must erase all protected information assets (communication and security configuration, user-set values, personal data, authentication values, and cryptographic keys) to prevent disclosure. To safely terminate use of a LOYTEC device:

1. Back up any required configuration (device backup protected by project password).
2. Perform a **factory reset / restore to defaults** (see LOYTEC Device User Manual). This erases all user data, user-set values, and credentials. The firmware version is retained.
3. If applicable, remove and physically destroy any SD card or removable storage media, or securely erase it.
4. Remove the device from any VPN, 802.1X, or management system (revoke its certificates and credentials in those systems).
5. Dispose of electronic waste in accordance with local regulations (e.g., WEEE in the EU).

Attention: Devices sold or disposed of with protected information assets not erased as described may expose configuration data, credentials, and building automation project data to the new owner of the device.

12.11 Information Policy

LOYTEC follows a policy for reporting, documenting and informing about potential security vulnerabilities and advisories:

- 1) The LOYTEC Web site offers a mailing list subscription to receive security-related information in a timely manner.
- 2) The LOYTEC Web site provides an interface to report any potential security vulnerabilities related to LOYTEC products. Incident reports can also be sent to security@loytec.com. A response will be sent with a trackable identifier. LOYTEC accepts security reports following common responsible disclosure practices containing technical information on how to reproduce the issues, exploit scripts or other information allowing to identify and close critical security issues.
- 3) LOYTEC commits to providing security fixes for zero-day exploits within 96 hours after their discovery. All other security-related fixes will be made available in the next firmware patch within 30 days.

13 Specifications

13.1 I/O Specification

13.1.1 UI - Universal Input

UIs are universal inputs for four different input types. They have an input voltage range of 0 to 10V, and can withstand up to 30V. The UIs correspond to class 1 with a relative accuracy of +/-1% (of measured value) between 1V and 10V, and an absolute accuracy of +/-10mV between 0V and 1V. The ADC resolution is 16 bits. Galvanically isolated sensors resp. switches must be connected. Universal inputs can be configured as:

- **Binary Input (Digital Input):** input impedance > 20kΩ, sampling period 10ms.
 - In voltage mode, the threshold values are < 0.8V for low level and > 2V for high level.
 - In resistance mode, the threshold values are < 1.9kΩ for low level and > 6.7kΩ for high level.

Between the threshold values, the resulting level of the UI is not defined.

- **Voltage Metering 0-10V:** input impedance > 20kΩ, sampling period < 1s.
- **Current Loop 4-20mA:** input impedance 249Ω, sampling period < 1s. An internal shunt of 249Ω is available for some universal inputs. Otherwise, an external resistor of 249Ω must be used as a shunt.
- **Resistance Measurement:** input impedance 10kΩ, sampling period < 1s. Resistors in the range of 1kΩ to 100kΩ can be measured. A value > 500 kΩ is detected as a disconnected sensor, a value < 25Ω is detected as short-circuit (except if NoValCorr flag is set).

The average sampling period p of analog inputs depends on the number of active (non-disabled) universal inputs n that are configured in analog mode. The formula for p is:

$$p = n * 125ms$$

This means if e.g. only two UIs are configured as analog inputs, a new sample is taken every 250ms (on average) for each of the two inputs. The UIs configured as digital inputs are unaffected (sampling period always 10ms) by this formula.

For measuring room temperature LOYTEC suggests using NTC10k sensors. Because of their steep resistance characteristics around typical space temperature values no calibration is required and measurements have sufficient accuracy.

Because of the flat resistance characteristics of PT1000 and Ni1000 sensors the accuracy of space temperature measurements is lower. Therefore, PT1000 and Ni1000 sensors require calibration on the LCD display of the device.

13.1.2 DI - Digital Input, Counter Input (S0-Pulse)

DIs are fast binary inputs, which can also be used as counter inputs (S0). They follow the S0 specification for electric meters and have a sampling period of 10ms. They change state at a load of 195Ω between the DI terminal and GND. Galvanically isolated sensors resp. switches must be connected.

13.1.3 AO - Analog Output

AOs are analog outputs with a signal range of 0 to 10V (up to 12V), a resolution of 10 bits, and a maximum output current of 10mA (short circuit proof). The accuracy over the whole range is +/-100mV.

13.1.4 DO - Digital Output

The following digital outputs are available:

- Relay 2A 24V Output: Switching capacity 2A, 24VAC/24VDC (resistive). This output is designed to connect external interface relays.
- Relay 2A Output: Switching capacity 2A, 250VAC resp. 30VDC. Max in-rush current 2A, max. 300W (resistive) @ 250VAC.
- Relay 6A Output: Switching capacity 6A, 250VAC resp. 30VDC. Max in-rush current 6A, max. 600W (resistive) @ 250VAC.
- Relay 10A Output: Switching capacity 10A, 250VAC resp. 30VDC. Max in-rush current 10A, max. 1600W (resistive) @ 250VAC.
- Relay 10A Type2: Same as 10A relay, but switching DC voltage is not UL rated.
- Relay 16A Output: Switching capacity 16A, 250VAC resp. 30VDC. Max in-rush current 80A, max. 2000W (resistive) @ 250VAC. Note, that switching DC voltage is not UL rated.
- TRIAC Output: Switching capacity 0.5A, 24 to 230VAC. No external relays must be connected.

When switching higher loads than specified an interface relay must be used. When connecting an external interface relay to a L-IOB relay, a quenching circuit like a varistor or RC element must be used. For the actually available relays on L-IOB models refer to the specification tables in the Sections 13.3 and below.

13.1.5 PRESS - Pressure Sensor

These inputs represent differential pressure sensors which measure pressures from -500 to +500 Pascal at 14-Bit resolution. They are equipped with two 3/16" (4.8 mm) hose connectors.

13.1.6 IO – Universal Analog/Digital Input/output

This kind of terminal hardware is configurable to behave like a universal input (as described in Section 13.1.1) or as an analog output (as described in Section 13.1.3).

The terminals have an input voltage range of 0 to 10V, and can withstand up to 30V. The IOs correspond to class 1 with a relative accuracy of +/-0.5% (of measured value) between 1V and 10V, and an absolute accuracy of +/-5mV between 0V and 1V. The ADC resolution is 12 bits. Galvanically isolated sensors resp. switches must be connected. The sampling period of IO inputs is 50ms. This limits Pulse Count inputs to a maximum frequency of 10 Hz.

In output mode, the terminals have a signal range from 0 to 10V, a resolution of 12 bits, and a maximum output current of 2mA (short circuit proof). The accuracy over the whole range is +/-100mV. If used as digital output (0V or 10V) the maximum output current is 20mA.

13.1.7 O – 4-20mA Current Output

O-terminals are analog current outputs with a signal range of 4-20mA and a resolution of 12 bits.

13.2 Internal Translation Tables

The L-IOB devices offer fixed internal translation tables for easy configuration of some temperature sensors. The xin/xout values of these tables are listed in Table 5.

xout: Temp. [°C]	xin: Resistance [Ω]			
	PT1000	NTC10K	NTC1K8	Ni1000
-30	882.2	176680	24500	842
-20	921.6	96970	14000	893
-10	960.9	55300	8400	946
0	1000.0	32650	5200	1000
10	1039.0	19900	3330	1056
20	1077.9	12490	2200	1112
25	1097.4	10000	1800	1141
30	1116.7	8060	1480	1171
40	1155.4	5320	1040	1230
50	1194.0	3600	740	1291
60	1232.4	2490	540	1353
70	1270.0	1750	402	1417
80	1308.9	1260	306	1483
90	1347.0	920	240	1549
100	1385.0	680	187	1618
120	1460.6	390	118	1760

Table 5: Internal translation table values

13.3 Specification for LIOB-18x Models

Dimensions [mm]	107 x 100 x 75 (L x W x H)				
Operating Temperature (ambient)	0°C to +50°C				
Storage Temperature	-10°C to +85°C				
Humidity (non condensing) operating / storage	10 to 90 % RH				
Environmental Protection	IP 40 (enclosure); IP 20 (screw terminals)				
Power Supply	24 VDC / 24 VAC ± 10 %				
Installation	DIN rail mounting (EN 50 022)				
Interface	1 x CEA-709/FT				
Types	LIOB-180	LIOB-181	LIOB-182	LIOB-183	LIOB-184
Power Consumption [W]	1.7 / 2.6 (all Relays on)	1.7	1.7 / 2.7	1.7 / 2.5	1.7 / 2.5
Universal Input (UI)	8	8	6	6	7
Digital Input (DI)	2	12	-	-	-
Analog Output (AO)	2	-	6	6	4
Digital Output (DO)	8 (4 x Relay 6A, 4 x Triac)	-	8 (8 x Relay 6A)	5 (4 x Relay 16 A, 1 x Relay 6 A)	7 (5 x Relay 6A, 2 x Triac)
Digital output specification	Relay: 6A 250VDC/30VDC, 600W (resistive) @ 250VAC Triac: 0.5 A @ 24-230 VAC	-	Relay: 6A 250VDC/30VDC, 600W (resistive) @ 250VAC	Relay: 16A 250VAC/30VDC ¹ , 2000W (resistive) @ 250VAC, in-rush 80A Relay: 6A 250VDC/30VDC, 600W (resistive) @ 250VAC	Relay: 6A 250VDC/30VDC, 600W (resistive) @ 250VAC Triac: 0.5 A @ 24-230 VAC
Pressure Sensor	-	-	-	-	± 500 Pa (14 Bit)
Internal shunt available for current measurement	UI5 & UI6, UI7 & UI8	UI5 & UI6, UI7 & UI8	UI3 & UI4, UI5 & UI6	UI3 & UI4, UI5 & UI6	UI5 & UI6, UI7
Supported STId card readers	3	2	-	-	1

¹ Switching DC voltage is not UL rated.

13.4 Specification for LIOB-48x Models

Dimensions [mm]	107 x 100 x 75 (L x W x H)				
Operating Temperature (ambient)	0°C to +50°C				
Storage Temperature	-10°C to +85°C				
Humidity (non condensing) operating / storage	10 to 90 % RH				
Environmental Protection	IP 40 (enclosure); IP 20 (screw terminals)				
Power Supply	24 VDC / 24 VAC $\pm$ 10 %				
Installation	DIN rail mounting (EN 50 022)				
Interface	1 x IP-852				
Types	LIOB-480	LIOB-481	LIOB-482	LIOB-483	LIOB-484
Power Consumption [W]	1.7 / 2.6 (all Relays on)	1.7	1.7 / 2.7	1.7 / 2.5	1.7 / 2.7
Universal Input (UI)	8	8	6	6	7
Digital Input (DI)	2	12	-	-	-
Analog Output (AO)	2	-	6	6	4
Digital Output (DO)	8 (4 x Relay 6A, 4 x Triac)	-	8 (8 x Relay 6A)	5 (4 x Relay 16 A, 1 x Relay 6 A)	7 (5 x Relay 6A, 2 x Triac)
Digital output specification	Relay 6A 250VDC/30VDC, 600W (resistive) @ 250VAC	-	Relay 6A 250VDC/30VDC, 600W (resistive) @ 250VAC	Relay 16A 250VAC/30VDC ¹ , 2000W (resistive) @ 250VAC, in-rush 80A Relay 6A 250VDC/30VDC, 600W (resistive) @ 250VAC	Relay: 6A 250VDC/30VDC, 600W (resistive) @ 250VAC Triac: 0.5 A @ 24-230 VAC
Pressure Sensor	-	-	-	-	$\pm$ 500 Pa (14 Bit)
Internal shunt available for current measurement	UI5 & UI6, UI7 & UI8	UI5 & UI6, UI7 & UI8	UI3 & UI4, UI5 & UI6	UI3 & UI4, UI5 & UI6	UI5 & UI6, UI7
Supported STId card readers	3	2	-	-	1

¹ Switching DC voltage is not UL rated.

13.5 Specification for LIOB-580/581/582/583/584 Models

Dimensions [mm]	107 x 100 x 75 (L x W x H)				
Operating Temperature (ambient)	0°C to +50°C				
Storage Temperature	-10°C to +85°C				
Humidity (non condensing) operating / storage	10 to 90 % RH				
Environmental Protection	IP 40 (enclosure); IP 20 (screw terminals)				
Power Supply	24 VDC / 24 VAC $\pm$ 10 %				
Installation	DIN rail mounting (EN 50 022)				
Interface	1 x BACnet/IP				
Types	LIOB-580	LIOB-581	LIOB-582	LIOB-583	LIOB-584
Power Consumption [W]	1.7 / 2.6 (all Relays on)	1.7	1.7 / 2.7	1.7 / 2.5	1.7 / 2.7
Universal Input (UI)	8	8	6	6	7
Digital Input (DI)	2	12	-	-	-
Analog Output (AO)	2	-	6	6	4
Digital Output (DO)	8 (4 x Relay 6A, 4 x Triac)	-	8 (8 x Relay 6A)	5 (4 x Relay 16 A, 1 x Relay 6 A)	7 (5 x Relay 6A, 2 x Triac)
Digital output specification	Relay: 6A 250VDC/30VDC, 600W (resistive) @ 250VAC Triac: 0.5 A @ 24-230 VAC	-	Relay: 6A 250VDC/30VDC, 600W (resistive) @ 250VAC	Relay: 16A 250VAC/30VDC ¹ , 2000W (resistive) @ 250VAC, in-rush 80A Relay: 6A 250VDC/30VDC, 600W (resistive) @ 250VAC	Relay: 6A 250VDC/30VDC, 600W (resistive) @ 250VAC Triac: 0.5 A @ 24-230 VAC
Pressure Sensor	-	-	-	-	$\pm$ 500 Pa (14 Bit)
Internal shunt available for current measurement	UI5 & UI6, UI7 & UI8	UI5 & UI6, UI7 & UI8	UI3 & UI4, UI5 & UI6	UI3 & UI4, UI5 & UI6	UI5 & UI6, UI7
Supported STId card readers	3	2	-	-	1

¹ Switching DC voltage is not UL rated.

13.6 Specification for LIOB-585/586/587/588/589

Dimensions (L x W x H) [mm]	164 x 100 x 75, LIOB-585: 107 x 100 x 75			
Operating Temperature (ambient)	0°C to +50°C			
Storage Temperature	-10°C to +85°C			
Humidity (non condensing) operating / storage	10 to 90 % RH			
Environmental Protection	IP 40 (enclosure); IP 20 (screw terminals)			
Power Supply	24 VDC / 24 VAC $\pm$ 10 %			
Installation	DIN rail mounting (EN 50 022)			
Interface	1 x BACnet/IP, 1 x RS-485, 1 x EXT (MP-Bus on LIOB-585), 2 x USB			
Types	LIOB-585	LIOB-586/587	LIOB-588	LIOB-589
Power Consumption [W]	4.5	4.5 (relays on)	4.5 (relays on)	4.5 (relays on)
Universal Input (UI)	6	6	10	10
Digital Input (DI)	-	4	-	6
Analog Output (AO)	2	-	6	6
Digital Output (DO)	5 (5 x Triac)	6 (6 x Relay 10A Type2)	8 (8 x Relay 6A)	4 (4 x Relay 6A)
Digital output specification	Triac: 0.5 A @ 24-230 VAC	Relay: 10A Type2 250VAC/30VDC ¹ , 1600W (resistive) @ 250VAC LIOB-587: Power Measurement	Relay: 6A 250VAC/30VDC, 600W (resistive) @ 250VAC	Relay: 6A 250VAC/30VDC, 600W (resistive) @ 250VAC
Pressure Sensor	$\pm$ 500 Pa (14 Bit)	-	-	-
Internal shunt available for current measurement	UI3 & UI4, UI5 & UI6	UI3 & UI4, UI5 & UI6	UI3 & UI4, UI5 & UI6	UI3 & UI4, UI5 & UI6
Supported STId card readers	2	3	3	3

¹ Switching DC voltage is not UL rated.

13.7 Specification for LIOB-590/591/592

Types	LIOB-590	LIOB-591	LIOB-592
Dimensions (L x W x H) [mm]	107 x 100 x 75	177.1 x 86.54 x 46	159 x 100 x 75
Operating Temperature (ambient)	0°C to +50°C	0°C to +45°C	0°C to +50°C
Storage Temperature	-10°C to +85°C		
Humidity (non condensing) operating / storage	10 to 90 % RH		
Environmental Protection	IP 40 (enclosure); IP 20 (screw terminals)	IP 30 (enclosure); IP 20 (screw terminals)	IP 40 (enclosure); IP 20 (screw terminals)
Power Supply	24 VDC / 24 VAC ± 10 %	85 – 240 VAC / 50 – 60 Hz	24 VDC / 24 VAC ± 10 %
Installation	DIN rail mounting (EN 50 022)	two oblong holes ($\varnothing$ 7 mm, distance 315 mm)	DIN rail mounting (EN 50 022)
Interface	2 x Ethernet	2 x Ethernet, 2 x USB, RS-485, DALI	2 x Ethernet, 2 x USB, L-STAT
Power Consumption [W]	4.5*	15*	4.5*
Universal I/O (IO)	20	20	40
Digital Output (DO)	-	1 x Triac 1250W, 230VAC (connector for safety device) 3 x Triac 300W, 230VAC	-
Internal shunt available for current measurement	IO1 – IO20	IO1 – IO8	IO1 – IO40
Internal reference voltage available for resistance measurement	IO1 – IO20	IO1 – IO8	IO1 – IO40
Fan Speed Measurement	-	IO2, IO4	-
Supported STId card readers	-	-	-

* Add external load: Sum of max. current drawn from all outputs x 24V + power drawn from USB and L-STAT connectors.

13.8 Specification for LIOB-593/594/595/596

Types	LIOB-593	LIOB-594	LIOB-595	LIOB-596
Dimensions (L x W x H) [mm]	107 x 100 x 75			
Operating Temperature (ambient)	0°C to +50°C			
Storage Temperature	-10°C to +85°C			
Humidity (non condensing) operating / storage	10 to 90 % RH			
Environmental Protection	IP 40 (enclosure); IP 20 (screw terminals)			
Power Supply	24 VDC / 24 VAC ± 10 %			
Installation	DIN rail mounting (EN 50 022)			
Interface	2 x Ethernet, 2 x USB, L-STAT, MP-Bus			
Power Consumption [W]	4.5*			
Universal I/O (IO)	16	8	6	8
Internal shunt available for current measurement	IO1 – IO8		IO1 – IO6	IO1 – IO8
Internal reference voltage available for resistance measurement	IO1 – IO8		IO1 – IO6	IO1 – IO8
Digital Output (DO)	7 (5 x Relay 2A, 2 x Relay 6A)	7 (5 x Relay 2A, 2 x Relay 6A)	4 (4 x Relay 2A 24V)	6 (4 x Relay 2A 24V, 2 x Triac)
Digital output specification	Relay 2A 250VAC/30VDC, 300W (resistive) @ 250V Relay 6A 250VAC/30VDC, 600W (resistive) @ 250V	Relay 2A 250VAC/30VDC, 300W (resistive) @ 250V Relay 6A 250VAC/30VDC, 600W (resistive) @ 250V	Relay 2A 24VAC/24VDC (resistive)	Relay 2A 24VAC/24VDC (resistive) Triac: 0.5 A @ 24-230 VAC
Pressure Sensor	-	-	± 500 Pa (14 Bit)	-
Fan Speed Measurement	-	-	-	-
Supported STId card readers	-	-	-	-

* Add external load: Sum of max. current drawn from all outputs x 24V + power drawn from USB connectors

13.9 Resource Limits

Table 6 specifies the resource limits of the different L-IOB models. The V2 models have the same resource limits as their predecessors. The terminal limit defines the maximum number of usable L-IOB terminals on connected L-IOB I/O modules (i.e. terminals on the extension modules).

Model Limits	18x	48x	580/881/ 582/583/ 584	585	586/587 588/589
Total number of data points	2,000			10,000	
OPC Tags	-	300		5,000	
User Registers	1,000			5,000	
IEC61131 Variables	1,000				
CEA-709 NVs	200		-	500	
CEA-709 Alias NVs	200		-	500	
CEA-709 Address table entries/non-ECS	256/15		-	256/15	
BACnet Server Objects	-	-	300	500	
BACnet Client Mappings	-	-	300	500	
Calendar Patterns	25				
Scheduler objects	10 (max. AST configuration size 384KB, 64 data points per scheduler)		10		
Alarm Servers	1		32		
Trend Logs	-	50		256	
Total trended data points	-	100		256	
Total aggregated size	-	6 MB		200 MB	
E-mail templates	-	20		50	
Math objects	-	20		50	
Alarm Logs	-	5		10	
Modbus data points	-	-	-	300	
M-Bus data points	-	-	-	-	300
EnOcean data points	-	-	-	100	
OPC Client Devices	-	-	-		
Connections (local)	200			500	
Connections (global)	-	100			
L-WEB Clients (concurrent)	-	8		32	
Extension with external L-IOB Modules	-	1 x LIOB-45x	1 x LIOB-55x/56x	-	1 x LIOB-10x/11x or 1 x LIOB-55x/56x
Terminal limit (extension)	-	50	50	-	50
LWLAN-800 AP+Mesh max clients	-	-	-	7	

Table 6: Resource limits of different L-IOB models

Model Limits	590	591	592	593	594/595 596
Total number of data points	10,000				
OPC Tags	5,000				
User Registers	5,000				
IEC61131 Variables	1,000				
CEA-709 NVs	500	-	500	1,000	500
CEA-709 Alias NVs	500	-	500	1,000	500
CEA-709 Address table entries/non-ECS	256/15	-	256/15		
BACnet Server Objects	500			1,000	500
BACnet Client Mappings	500			200	500
Calendar Patterns	25				
Scheduler objects	10				
Alarm Servers	32				
Trend Logs	256				
Total trended data points	256	256	500	256	256
Total aggregated size	200 MB				
E-mail templates	50				
Math objects	50				
Alarm Logs	10				
Modbus data points	300			500	300
M-Bus data points	-				
EnOcean data points	-	100			
OPC Client Devices	2				
Connections (local)	500				
Connections (global)	100				
L-WEB Clients (concurrent)	32				
Extension with external L-IOB Modules	-	1 x LIOB-55x/56x	-	1 x LIOB-55x/56x	-
Terminal limit (extension)	-	50	-	50	-
LWLAN-800 AP+Mesh max clients	-	7			

Table 7: Resource limits of different L-IOB models (cntd)

14 References

- [1] LOYTEC Device User Manual 8.6, Delta IBT (Europe) GmbH, Document № 88086514, August 2026.
- [2] LINX Configurator User Manual 8.6, Delta IBT (Europe) GmbH, Document № 88086713, August 2026.
- [3] NIC User Manual 4.2, Delta IBT (Europe) GmbH, Document № 88067217, May 2013.
- [4] L-IOB I/O Modules User Manual 8.6, Delta IBT (Europe) GmbH, Document № 88078519, August 2026.

15 Revision History

Date	Version	Author	Description
2016-03-23	6.0	STS	Re-organized User Manual structure, branched out common parts into LOYTEC Device User Manual and LINX Configurator User Manual.
2017-04-24	6.2	STS	Added new L-IOB models. Section 11.1.4 specification for DO updated.
2018-05-15	6.4	STS	Added LIOB-585 model.
2019-05-15	7.0	STS	Updated for firmware 7.0.0.
2020-04-30	7.2	STS	Updated for firmware 7.2.0. Added LIOB-590 model. Documented LWLAN-800 client limitation.
2021-01-29	7.4	STS	Updated for firmware 7.4.0. Documented LRS232-802 usage. Updated Chapter 12 Security Hardening Guide. Added LIOB-591/592/593/594 models.
2022-02-03	7.6	ND	Updated for firmware 7.6.0. Updated Chapter 12 Security Hardening Guide. Added LIOB-587/595/596 models.
2023-03-30	8.0	STS	Updated for firmware 8.0.0. Updated Chapter 12 Security Hardening Guide. Updated L-IOB specification tables of Chapter 13. Section 13.8: Increased total trended data points to 1000 for LIOB-59x.
2023-12-30	8.2	STS	Updated for firmware 8.2.0. Added reference to LIOB-560/562.
2025-07-30	8.4	STS	Updated for firmware 8.4.0. Updated Chapter 12 Security Hardening Guide. Added Section 5.5 Getting started with L-STUDIO. Section 13.1.1: Added short circuit detection to resistance signal type.
2026-08-30	8.6	DH, STS	Updated the company name throughout the manual. Updated for firmware 8.6.0. Updated Chapter 11.3 Physical connection of outputs. Added description for 6/10A relays of LIOB-586/587/588/589 Chapter 12 Security Hardening Guide: Added Firmware Upgrade Cyber Security Disclaimer and Secure Disposal and Decommissioning section. Chapter 12.11 Information Policy: Added responsible disclosure statement to align with the Cyber Security Guideline.