

# LIOB-A2 Adapter

## Installation instructions

Instructions de montage


Montageanweisung


Montagevoorschrift

Istruzioni di montaggio


Instrucciones de montaje

Monteringsanvisning





Connectors		
LIOB CONNECT IN/OUT	1	SEL
	2	GND
	3	A, Noninverting Input/Output
	4	B, Inverting Input/Output
	5	TERM
POWER SUPPLY	6	Input 24 V PLUS
	7	Input GND
POWER OUTPUT max. 100mA	8	Output 24 V PLUS
	9	Output GND





35 mm x 7.5 mm DIN rail (EN 50022, BS 5584, DIN 46277-3)

