

LOYCNV-VA8 Voltage / Current Converter

Installation instructions

Instructions de montage


Montageanweisung


Montagevoorschrift

Istruzioni di montaggio

Instrucciones de montaje


Monteringsanvisning






CONNECTORS		
Input 24V DC max. 300 mA	01 02	Power Supply input - Power Supply input +

CONNECTORS		top	bottom
ANALOG INPUT 0 - 10V $R_{IN} > 1 M\Omega$	03	Input AI1	GND
	04	Input AI2	GND
	05	Input AI3	GND
	06	Input AI4	GND
	07	Input AI5	GND
	08	Input AI6	GND
	09	Input AI7	GND
	10	Input AI8	GND
4-20mA OUTPUT $250 \Omega \leq R_{SHUNT} \leq 600 \Omega$	11	Output O1	GND
	12	Output O2	GND
	13	Output O3	GND
	14	Output O4	GND
	15	Output O5	GND
	16	Output O6	GND
	17	Output O7	GND
	18	Output O8	GND




Weidmüller
BLZP 5.08/02/180

0.2 - 2.5 mm²




Weidmüller
B2CF 3.50/04/180

0.14 - 1.5 mm²
AWG26-AWG16



35 mm x 7.5 mm DIN rail (EN 50022, BS 5584, DIN 46277-3)



Device type

Date Code

Serial number of the device

